


To assemble chairs





Please note the following information:

- A. During assembly children should be kept away from the product due to possible risk of injury.
- B. Do not use this item if any components are missing or damaged.
- C. This product is suitable for children in the age range of 2-6 years.
- D. Maximum weight: tested and passed up to 30kg.
- E. No tools are required to assemble this product.
- F. **CARE INSTRUCTION:** Wash or clean with soap and warm water.
- G. **IMPORTANT:** Retain these instructions for future reference.

Customer Service:
 customer.services@libertyhousetoys.co.uk

To assemble table

Push with force to ensure the legs are fixed properly.



Top fits snugly on to table base (complete with plug).

Plug for use with sand and water play.

Remove the plug to release the sand or water after use.