


Liberty House Toys White Wooden Dress Up Unit Item Code: TF4917





CARE/CLEANING INSTRUCTIONS

- Wipe furniture with a soft dry cloth, do not use paper as this may be abrasive to the finish.
- The unit should be cleaned with a damp cloth and dried with a dry cloth.
- DO NOT use bleach or chemical solutions to clean the product.
- DO NOT expose to sunlight or other heat sources for a prolonged period.
- DO NOT store or leave outside.
- Periodically check the tightening of legs and screws.

1





∦₽ ٦ I c D ВМ M M M Ĵ₽ 〕 F

ΞI С

Step 3 С M E J ۱M Ø (a) 180°

Step 5 M M M \$ M ģ ġ







Step 4

Step 2



