


Liberty House Toys Safari Book Display Unit with Fabric Storage Boxes Item Code: TF5007






- Wipe furniture with a soft dry cloth, do not use paper as this may be abrasive to the finish.
- The unit should be cleaned with a damp cloth and dried with a dry cloth.
- DO NOT use bleach or chemical solutions to clean the product.
- DO NOT expose to sunlight or other heat sources for a prolonged period.
- DO NOT store or leave outside.
- Periodically check the tightening of legs and screws.





TOOLS REQUIRED:


Phillips Head Screw Driver (not supplied)
Flat Head Screw Driver (not supplied)




Step 1








Step 5





LIBERTY HOUSE

Liberty House Toys 20-24 Gibraltar Row King Edward Industrial Estate Liverpool L3 7HJ United Kingdom

MARNING: CHOKING HAZARD – Small parts.