HOW TO FIT YOUR EVENTER SERIES VEST

To ensure your Tipperary body protector offers the optimum level of protection, it is important that it fits correctly.

WHAT YOU NEED

- A soft fabric measure tape with inches or centimeters. Don't have one? You can download and **make your own here.** All you need is a pair of scissors and clear tape.
- A chair with a hard seat.
- A friend to help.
- Wear a T-shirt

HOW TO MEASURE

This vest requires measurements of the chest, waist and spine. Remember, these vests are designed to fit snugly. If your measurements fall between sizes, the best fit is usually the smaller size.


- Chest: Under the arms at the widest part across the chest to a snug fit.
- Waist: At natural waist.
- Spine: Sit in the chair. Measure from the base of the neck to chair. Subtract 2 inches or 5 cm from that measurement which will ensure the vest does not interfere with the saddle while riding.

PUTTING ON YOUR VEST

- Each time you put on your Eventer Series vest, make sure the laces are loose to prevent undue stress on the zipper.
- Make sure the zipper is seated well and do it up.
- Adjust the laces to ensure a snug fit.

For more assistance, please contact: **Customer Care**

- T: 888.313.8842 toll free
- T: 905.738.9944
- E: info@tipperaryequestrian.com



VEVENTER PRO								V EVENTER						
	CHEST		WAIST		SPINE				CHEST		WAIST		SPINE	
SIZE	IN	СМ	IN	СМ	IN	СМ		SIZE	IN	СМ	IN	СМ	IN	СМ
			YOUTH								YOUTH			
YXXS	26	65	24	60	16 1/2	41.50		YXXS	26	65	24	60	16 1/2	41.50
YXS	28	70	26	65	18 1/2	46.25		YXS	28	70	26	65	18 1/2	46.25
YS	30	75	28	70	20 1/2	51.75		YS	30	75	28	70	20 1/2	51.75
YM	32	80	26	65	20 1/2	51.75		YM	32	80	26	65	20 1/2	51.75
YL	34	85	28	70	20 1/2	51.75		YL	34	85	28	70	20 1/2	51.75
YXL	36	90	30	75	20 1/2	51.75		YXL	36	90	30	75	20 1/2	51.75
	REGULAR							REGULAR						
XXS	32	80	30	75	20 1/2	51.75		XXS	32	80	26	65	22 V2	56.75
xs	34	85	28	70	22 1/2	56.75		XS	34	85	28	70	22 ^{1/2}	56.75
s	36	90	30	75	22 V2	56.75		S	36	90	30	75	22 V2	56.75
м	38	95	32	80	22 1/2	56.75		м	38	95	32	80	22 1/2	56.75
L	40	100	34	85	22 1/2	56.75		L	40	100	34	85	22 1/2	56.75
XL	42	105	36	90	22 1/2	56.75		XL	42	105	36	90	22 1/2	56.75
TALL											TALL			
TS	36	90	30	75	24 1/2	61.75		TS	36	90	30	75	24 1/2	61.75
тм	38	95	32	80	24 1/2	61.75		тм	38	95	32	80	24 1/2	61.75
TL	40	100	34	85	24 1/2	61.75		TL	40	100	34	85	24 1/2	61.75

