


CHOOSING THE CORRECT SIZE GLASS DOORS

BEFORE YOU BUY, GET THE RIGHT FIT



1. Measure the inside width (W) of your fireplace opening.
2. Measure the inside height (H) of your fireplace opening from the floor to the inside top of opening.
3. Check both measurements and be sure they are accurate to the nearest 1/8".

WARNING: If the fireplace opening height and width DOES NOT fall within the size chart range, then these fireplace glass doors WILL NOT FIT.

PLEASANT HEARTH FIREPLACE GLASS DOORS SIZE CHART			
Size	Fits Opening		Overall Dimensions
	Width	Height	
small	30" – 37"	22-1/2" – 29-1/2"	37-1/2" W – 30" H
medium	30" – 37"	25-1/2" – 32-1/2"	37-1/2" W – 33" H
large	36" – 43"	25-1/2" – 32-1/2"	43-1/2" W – 33" H

Note: The glass doors are designed to surface mount on the outside of a flat surface such as brick or marble. Use the Size Chart above to determine the correct size before you buy.

FOR MASONRY FIREPLACES ONLY Not For Prefabricated Fireplaces



MASONRY



Indicators that you have a masonry fireplace:

1. Made completely of brick and mortar
2. Built into the home when the home was constructed; more common in older homes
3. The chimney is part of the home's original design



PREFABRICATED



Indicators that you have a prefabricated fireplace:

1. More common in newer homes
2. Inside of the fireplace is usually built from solid sheets of metal or refractory panels that look like bricks
3. The flue is metal



See our installation video here:

<https://www.youtube.com/watch?v=reR-LUvI62g>

FOR SAFE USE: Always keep mesh panels closed and the glass doors open when fire is burning in fireplace.



GHP is not responsible for the purchasing of incorrect size (see sizing information, before you buy). Also, we are not responsible for incorrect usage of product.