

AIR HUMIDIFIER

USER MANUAL



High Mist Output




Innovative Design



Automatic Shut-off



Whisper-quiet



WARRANTY

- Your product is guaranteed by us for 12 months from your original date of purchase. If you want to extend your warranty for one more year, please do not hesitate to contact us.
- Become a MegaWise member and get access to exclusive benefits, such as updates about the latest MegaWise products.

1. Share your experience by leaving an honest review.



Please leave a review with accompanying photos or a video would be greatly appreciated!

 Add photos/video

Submit

2. CONTACT US

Please scan the QR-code to start chatting (Live chat).



SCAN ME


or visit:

m.me/MegaWiseUSA

or

<http://megawise.com>

DESCRIPTION OF THE PARTS 1



2 SAFETY MEASURES

1. Before using the device, please attentively read these instructions and keep them for future reference.
2. Before switching on the unit, make sure that the household mains voltage corresponds to the operating voltage of the unit.
3. Place the unit on a flat, moisture-resistant surface. Distance from the walls should not be less than 15 cm.
4. Do not direct the nozzle of the unit at wooden furniture, electrical appliances, books or any objects which can be damaged by moisture.
5. Do not place the humidifier in the places subjected to direct sunlight, high temperatures, near computers or other sensitive electronic appliances.
6. Do not leave the unit unattended in closed rooms, otherwise condensation can build on the furniture and walls. It is recommend to keep the door of the room where the humidifier is used, half-opened.
7. This unit is not intended for use by children or disabled persons unless they are given all the necessary instructions on safety measures and information about the dangers which can be caused by improper usage of the unit.
8. Do not switch on the unit without water in it. Disconnect the unit from the power supply when the water tank becomes empty.
9. Always unplug the unit before taking the water tank out of the unit.

10. Do not block steam outlets and ensure that foreign objects do not get inside them.
11. Do not immerse the unit, the power plug or the power cord into water or other liquids.
12. Do not move or tilt the unit during its operation.
13. Do not touch the unit's plug with wet hands. Unplug the unit before moving it to another location.
14. Before using the unit, closely examine the power cord and make sure that it is not damaged. Do not use the unit if its power cord is damaged.
15. Use only the removable parts which are supplied with the unit. Do not dismantle the unit yourself. If the unit malfunctions, please contact customer service.
16. Always unplug the unit and pour out water from the water tank during cleaning the unit, or you do not intend use it.
17. Regularly clean the unit and inspect the sprayer for cracks.
18. For household use only.

4 USE OF THE HUMIDIFIER


Unpack the device and remove all packaging materials. Inspect the device for damage. If there is any damage, do not turn on the device.

Note:

- Use clean water at temperature of $\leq 104^{\circ}\text{F}/40^{\circ}\text{C}$. It is recommended to use purified water.
- Suitable to use at temperatures of $40\text{-}104^{\circ}\text{F}/5\text{-}40^{\circ}\text{C}$ with relative humidity of $\leq 80\%$.

Before plugging in, ensure that the household mains voltage corresponds to the operating voltage of the device.

1. Remove the nozzle, turn the water tank up side down, remove the stopper (turn counterclockwise) and fill the water tank with the quantity of water desired.
2. Replace the stopper and seal it by turning clockwise.
3. Invert the tank and carefully place it back on the unit base.
4. Replace the nozzle and plug in the humidifier.
5. Twist the knob clockwise on the unit base, the indicator will light up green and the humidifier will begin producing vapor.



Warning:

1. Always switch off and unplug the unit before cleaning.
2. Hard water causes the appearance of scale on the “sprayer” and in the operating chamber; it leads to improper operation of the unit and the appearance of white deposit on interior objects.
3. Use boiled water, distilled water, water which has stood for some time or purified water.
4. Change water in the water tank frequently.
5. Once a week, carefully wash the water tank with a neutral washing liquid solution. Afterwards rinse it thoroughly with water.
6. Add 5-10 drops of the cleaning agent on the “sprayer” and wait about 2-5 minutes. Use the brush to remove deposits from the surface of the “sprayer”.

Note

As a cleaning agent for the “sprayer”, you can use the same substances that are used for scale removal in kettles.

Do not immerse the unit in water or other liquids.

Storage

1. Turn off and unplug the humidifier.
2. Pour out water from the water tank .
3. Store the humidifier in a dry cool place out of reach of children.

6 TROUBLESHOOTING

Please check the below table if you are experiencing any issues with the humidifier:

Failure	Possible causes	Troubleshooting
Indicator does not light up, no mist output.	Unit is not plugged in.	Plug in the unit.
		Ensure the device is properly plugged in and that the power socket is in good operating condition.
Indicator light is red, no mist output.	There is no water in the water tank.	Fill the water tank with water.
The mist has an unpleasant odor	This normal if the device is new.	Empty the water tank and allow to stand for 12 hours before using again.
	Polluted or stagnant water	Unplug the unit, remove the water tank, pour out water, wash the water tank, and fill the water tank with boiled or distilled water.
Mist output is low.	Dirty sprayer	Unplug the unit and clean the sprayer
Abnormal noise during operation.	The unit is placed on an uneven or unstable surface.	Unplug the unit and move it to a location with a flat, even surface.

NOTE:

Mineral deposits caused by hard water may affect the overall performance of the unit. In this case, remove the mineral deposits by cleaning the unit. If the tap water used is too hard, try using purified water with tap water at a ratio of 1:1.

CONTENTS

Instruction manual – 1 pc.

Removable nozzle - 1 pc.

Removable water tank – 1 pc.

Removable water tank lid – 1 pc.

Technical specifications

Power supply: 100V-240v ~ 50 Hz/60Hz

Power consumption: 15W

The manufacturer preserves the right to change the design and the specifications of the unit without a preliminary notification.


GUARANTEE

Details regarding the guarantee can be obtained from the dealer whom the appliance was purchased from. The original sales receipt must be produced when making any claim under the terms of this guarantee.

Thank you for choosing this product. In order to understand how to easily use this product, please read this instruction manual carefully before using and retain it for future use. In the event that you need assistance using the appliance, please contact customer service.

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.

 Please scan QR-code to start chatting instantly:



Scan QR-code & Start Chatting



 support@megawise.com

 megawise.com

MEGAWISE



Made in China