




Select program



Auto Start



Stop



P_	
P_	
P_	
P_	
P_	
P_	
P_	
P_	
P_	
P_	
P_	
P_	



Zeit
Time
Temps
Tempo

Tiempo
Время смешивания
攪拌時間
시간



Drehzahl
Speed
Vitesse
Numero di giri

Velocidad de giro
Число оборотов
回転数
속도




Intervall
Interval
Intervalle
Intervallo

Intervalo
Интервал
インターバル
간격




Vakuu
Vacuum
Vide
Vuoto

Vacío
Вакуум
バキューム
진공




Vorvakuum
Pre-vacuum
Pré vide
Prevuoto

Prevacío
Предварительный вакуум
前バキューム
진공 전




Nachvakuum
Post-vacuum
Après vide
Postvuoto

Postvacío
Дополнительный вакуум
後バキューム
진공 후



Gips
Plaster
Plâtre
Gessi
Yeso
Гипс
石膏
깁스

Vorspateln
Premix
Pré malaxage
Pre-spatolazione
Premezclar
Предварительное
смешивание
前攪拌
프리믹스





Einbettmasse
Investment
Revêtements
Rivestimenti
Revestimientos
Паковочная масса
埋没材
매물재



Auswählen
Select
Sélectionner
Selezionare

1.


Seleccionar
Выбор
選擇する
선택



Einstellen
Adjust
Réglage
Impostazione

2.


Ajuste
Установка
設定する
조정



Speichern
Save
Mémorisation
Memorizzazione

3.

Memorización
Занесение в память
メモリーする
저장



2 Sec.

