



The TreeMendous Ornament Decorator®

INSTRUCTIONS

AGE 3+

IMPORTANT: Before Use: * Requires 3 AA Batteries (not included)
Remove screw from battery cover and insert 3 AA batteries.
Replace the battery cover and tighten screw.

How to enjoy your new TreeMendous Decorator!

STEP 1: Remove green cap. Align slotted groove on ornament with black lines on TreeMendous green connector.

STEP 2: Push firmly to secure ornament into the TreeMendous.

STEP 3: Turn on the TreeMendous Ornament Decorator®. On/off switch is located on the left side.

STEP 4: Remove lid/cap from marker and touch/apply the tip of the marker to the spinning ornament to create colorful designs. When finished decorating, allow 60 seconds to dry.


STEP 5: Remove ornament and replace green cap.
Your TreeMendous Ornament is complete!

HELPFUL HINTS:

- After decorating, make sure marker lids/caps are securely put back on markers to ensure a long usage.
- Remove batteries when storing The TreeMendous Ornament Decorator®.
- Please enjoy The TreeMendous Ornament Decorator® with friends and family.

* **Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.**

* **Do not mix old and new batteries.**



WARNING:

CHOKING HAZARD - Small Parts.
Not for children under 3 years.
ENTANGLEMENT HAZARD - Keep hair,
loose clothing, and jewelry away from
opening and all moving parts.



FROM THE
CREATORS OF THE
EGGMAZING!



Patent # 10,531,749
Hey Buddy Hey Pal Investments, LLC.
5402 Winners Circle
Amarillo, TX 79110
www.heybuddyheypal.com
info@heybuddyheypal.com