



# The Gift Box Ornament Decorator®

## INSTRUCTIONS

AGE 3+

**IMPORTANT: Before Use:** \* Requires 3 AA Batteries (not included)  
Remove screw from battery cover and insert 3 AA batteries.  
Replace the battery cover and tighten screw.

### How to enjoy your new Gift Box Decorator!

**STEP 1:** Remove silver cap. Align slotted groove on ornament with ridges on Gift Box green connector.

**STEP 2:** Push firmly to secure ornament into Gift Box Decorator®.

**STEP 3:** Turn on The Gift Box Ornament Decorator®. On/Off switch is located on the right side.

**STEP 4:** Remove lid/cap from marker and touch/apply the tip of the marker to the spinning ornament to create colorful designs. When finished decorating, allow 60 seconds to dry.



**STEP 5:** Remove ornament and replace silver cap.  
Your Gift Box Ornament is complete!

#### HELPFUL HINTS:

- After decorating, make sure marker lids/caps are securely put back on markers to ensure a long usage.
- Remove batteries when storing The Gift Box Ornament Decorator®.
- Please enjoy The Gift Box Ornament Decorator® with friends and family.

\* Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

\* Do not mix old and new batteries.



#### **WARNING:**

CHOKING HAZARD - Small Parts.  
Not for children under 3 years.  
ENTANGLEMENT HAZARD - Keep hair,  
loose clothing, and jewelry away from  
opening and all moving parts.



FROM THE  
CREATORS OF THE  
**EGGMazing!**

**Egg  
Mazing**®  
The Eggmazing Egg Decorator®

Patent # 10,531,749  
Hey Buddy Hey Pal Investments, LLC.  
5402 Winners Circle  
Amarillo, TX 79110  
www.heybuddyheypal.com  
info@heybuddyheypal.com