

### WARNING

- Do not open the device.
- Do not look directly into the light emitting lamp Risk of eye injuries!
- Do not operate in direct sunlight or extreme temperature conditions.
- Operating temperature, -10°C to +40°C.
- Keep away from children! Children should be supervised in order to ensure that they do not play with the device!

## OPERATING INSTRUCTIONS BR9501 TECHNICAL DATA

Light Source	High Power COB LED - Spotlight
	High Power COB LED - Flood Light
Lumen Output	Flood Light Full Power Mode - 700 Lumen
	Flood Light Normal Mode - 350 Lumens
	Flood Light ECO Mode - 100 Lumens
	Spotlight - 250 Lumens
<b>Operating Time</b>	Flood Light Full Power Mode- 2.5 Hours
	Flood Light Normal Mode - 4.5 Hours
	Flood Light ECO Mode - 10 Hours
	Spotlight - 4 Hours
Battery	Li-Ion 3.7 V, 2600 mAh, 9.62 Wh
Charging Time	4.5 Hours
Charging Input	DC 5V 1A
Environmental pr	otection IP65, IK07
Operating tempe	ature -10 °C to +40 °C

# **OPERATING & CHARGING PROCEDURE**

### **Operating Instructions**

- Press the ON/OFF Switch once: Spotlight will activate.
- Press the ON/OFF Switch twice: Flood Light 'ECO Mode' will activate.
- Press the ON/OFF Switch a third time: Flood Light 'Normal Mode' will activate.
- Press the ON/OFF Switch a fourth time: Flood Light 'Full Power Mode will activate.
- Press ON/OFF Switch a fifth time: Mini Camp Light will turn off.
- Battery Level Indicator provides at a glance battery status via 3 LEDs.

# Charging

- Switch lamp off during charging.
- Whilst charging the LED indicator will flash green.
- When charging is complete, the LED will illuminate solid green.

# NOTE

- Only use the supplied charging cable when charging the Mini Camp Light. The use of a NON-recommended charging cable can lead to malfunction of the Mini Camp Light or thermal incident.
- We recommend charging the Mini Camp Light for 4-5 hours before first use.
- Fully charge the Mini Camp Light before it is stored for a long periods.

# SAFETY INSTRUCTION

- Do not use the device if there is damage to the housing, plug or cable. Consult your local authorised specialist!
- Do not open the device! Repair work and replacing the rechargeable battery pack may only be carried out by an authorised specialist.
- Carry out cleaning tasks only when the mains plug is removed from the mains power!
- There is a risk of short-circuit. Repairs on the device may only be carried out by commissioned and trained persons. Please contact your nearest authorised specialist.
- Protect the battery against heat, eg. against continuous intense sunlight, fire, water, and moisture. Danger of explosion.
- If the battery is damaged or not used correctly, fluids can leak from the battery. Avoid contact with these. Leaking battery fluids can lead to skin irritation or burns. Rinse off with water if you should come into contact. If the fluid gets into your eyes, seek medical help.

## ENVIRONMENTAL PROTECTION

• The device should not be discarded in the normal household waste under any circumstances.



 Dispose of the device via an authorised disposal center or your communal waste disposal facility. Observe the current applicable regulations. Contact your waste disposal facility in the event of any doubt. Dispose of all packaging materials via an environmentally friendly disposal facility. Rechargeable batteries must not be disposed of in the household waste, dispose of them at a registered battery collection facility.

## WARRANTY STATEMENT

Brown & Watson International Pty Ltd (BWI) of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue will under normal use and service be free of failures in material and workmanship for a period of one (1) year from the date of the original purchase by the customer as marked on the invoice.

This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the purchaser. To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either

BWI or the retailer from where the product was bought in order that the warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage. This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

## IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### Distributed by

#### AUSTRALIA

Brown & Watson International Pty. Ltd.

1500 Ferntree Gully Road,

Knoxfield Victoria 3180

Phone: (03) 9730 6000


Fax: (03) 9730 6050

National Toll Free: 1800 113 443

#### NEW ZEALAND

Brown & Watson International NZ Ltd. 19 Bell Avenue, Mount Wellington, Auckland 1060, New Zealand Phone: (09) 525 4575





# RECHARGEABLE LED MINI CAMP LIGHT BR9501