

Melcome!



PLEASE TAKE A FEW MINUTES TO READ THROUGH THESE INSTRUCTIONS, THEY WILL HELP ENSURE YOU GET THE BEST FROM YOUR SMARTWATCH.

Our UK support team are on hand if you need any help with your watch...

CUSTOMERSERVICE@HENRY-LONDON.COM

+44 (0) 121 524 1400

Our team is available Monday - Friday 9am - 4pm. You'll find support on our website 24/7

WWW.HENRY-LONDON.COM

LET'S GET STARTED...SETTING UP

To switch on, long press the power button (crown) for 3 seconds.

To switch off, when time screen is displayed, long press the power button for 3 seconds & then long press the power button or the screen to confirm the power-off.

CHARGING YOUR WATCH

Please charge your watch fully before setting up. It is time to charge your watch when it displays 'low battery'.


1. Line up the charger pins to the 2 charging spots on the back of the watch, the pins are magnetic and will secure the charger in place.

2. Plug in the USB cable to a power source. Once connected, a charging icon will appear on screen.

Note - Approx 2 hour charge time is sufficient to fully charge your smartwatch, please do not overcharge your smartwatch.

FUNCTIONS NAVIGATION

You can navigate the watch by sliding left / right and up / down.



BUTTON OPERATION

SHORT PRESSING THE SIDE BUTTON:

- Unlocks the screen
- Returns to the always on dial LONG PRESSING THE SIDE BUTTON:
- Turns on / off the watch (You can also switch off or reset the watch through the settings)

PLEASE DOWNLOAD THE HENRY LONDON SMART APP TO GET STARTED.



SCAN THE QR CODE WITH YOUR SMARTPHONE CAMERA TO GO STRAIGHT TO THE APP, OR SEARCH HENRY LONDON SMART IN YOUR APP STORE.

COMPATIBILITY

The Henry London App. will work with the following smartphones...

Android (version 5.0 and above) Apple IOS (version 9.0 and above)

Please make sure the App. is the latest version and check for updates.

Bluetooth requirement 5.0. Bluetooth Range 10m.

CONNECTING YOUR WATCH

Within the App Settings menu, enter 'Device Management' then 'Bind' next search for the device you wish to connect to & confirm.

Visit our website if you'd like to see our connection video guide.

ALWAYS ON DIAL



While on the main dial, swipe down from the top and select 'Always On Display', which will allow you to switch on and select your preferred hours for this to be on. Note this will increase your battery consumption.

SELECTING YOUR DIAL

You have a range of bespoke Henry London dials to choose from. Within the App, access 'watch dial' then simply long press on the dial you want to select, it will automatically begin to transfer to your watch screen.

You can store up to six dials on your watch. To change these, delete from 'my watch faces'. Within the app, you can then select more from the watch dial section. To change your dial on your watch, press and hold the homescreen to swipe through your dials.

CUSTOMISING YOUR OWN DIAL



You can customise or select a photo from your smartphone gallery to use as your dial.

- Within the app, under device section select 'customised dial
- · Clicking the camera icon within the menu allows you to select a photo from your phones gallery and adjust to fit the dial screen.
- · You can edit the display information and colours.



Wellness

Heart Rate



The watch will record your heart rate during the day if activated in settings.

Sports



To start a sport select an exercise type in the menu option and tap to enable it. To pause or stop your exercise click the crown and follow the steps on the screen.

Breathing



It is important to take a few minutes out to practice a little mindfulness, this feature helps you focus on your breathing.

Lifetsyle

Call Notifications



Receive and reject call notifications.

Alarm



Within the watch menu you can set alarms.

Find My Watch



When connected via Bluetooth, our Find Device feature will vibrate and chime to help you locate your phone or watch.

Camera Control



Take pictures remotely from your smart watch.

Note: The phone needs to be unlocked and the app open for the watch to control the camera.

WATCH CARE

Your Henry London smartwatch is produced in stainless steel. Do not wear your smartwatch whilst applying sprays or creams. Do not allow contact with any corrosive agent e.g. paint, solvents or adhesives, as this may affect the finish of the smartwatch. Do not try to replace or disassemble the battery.

STRAP CARE

Environmental conditions can affect straps, please treat with care & limit exposure to direct heat & sunlight. Don't use chemical cleaners on your strap, avoid contact with cosmetics such as fake tan or perfumes. Clean light soiling with weak soapy water on a soft, damp cloth. Please be aware light coloured straps are prone to attract colour transfer from other materials and cosmetic substances. Please take care as discolouration of straps is not covered within the guarantee.

WATER RESISTANCE

Your watch is certified to IP67 standards. It can safely be immersed in water for up to 30 mins to a maximum depth of 1.0 Metre. We do not recommend our watches for use in salt water. Always rinse & dry your watch after any contact with water.

IMPORTANT SAFETY INFORMATION & WARNINGS

BEFORE USING THE PRODUCT, PLEASE FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE!

BATTERY WARNINGS Do not attempt to replace the battery, open the device enclosure or disassemble your HENRY DAT LEXT WARKINGS Up not attempt to replace the battery, open the device enclosure or disassemble your HEINRY LONDON product. Doing so can result in a safety hazard - The integrated rechargeable battery cannot be removed or replaced • Substances within HEINRY LONDON smartwatch battery may harm the environment or cause injury if handled or disposed of improperly. In the unlikely event of contact with battery acid, thoroughly flush the affected area with plenty of clean water and seek IMMEDIATE medical attention • When the battery is fully charged disconnect from charger, DO NOT exceed 2 hour charge time.

DEVICE WARNINGS This is a Class A product. In a domestic environment, this product may cause radio interference. In which case the user may be required to take adequate measures - Ensure your smartwatch correctly engages with the charging contacts - Before each use, please check the product for damage, do not use if the product is damaged - This is not a toy, children should not play with this product. Never attempt to open your smartwatch, this may result in danger. Protect the product from strong impacts, vibrations, direct sunlight and dirt - Do not place heavy objects on the product - Avoid strong magnetic fields e.g. loudspeakers - Salt and thermal water can lead to the corrosin of metal parts. Remove the product fore using saunas as the temperature difference can cause condensation - Do not operate the product hear heat sources e.g. radiators or other devices entiting heat. Do not cover the product during operation or charging - Never use the product the functionality of sensitive electronics - Do not use average cleaners to clean your HENRY LONDON product to extermely high rol we tamperatures or lites electronic systems. The wireless signals transmitted could impact the functionality of sensitive electronics - Do not use your HENRY LONDON product if the display is cracked - Do not expeare or operate your HENRY LONDON product to remove your HENRY LONDON product to remove your HENRY LONDON product to the display is cracked - Do not attempt to wear or operate your HENRY LONDON product to the functionality of product - Remove your HENRY LONDON product the product solutions on the product for a port place have obligations or other applications on the product slipplay while driving or in other situations where distractions could be hazardous. Always be aware of your surroundings when using HENRY LONDON products and services - Ensure your smartwatch is removed at regular intervals for genetic cleaning.

Menstrual Cycle



You can easily keep a track of your menstrual cycle within the app and watch.

HENRY

Reminder To Move



The device will notify to remind you to move after a period of inactivity. Note: You can edit the time, days and duration within the app.

Goals



Messages

A reminder will pop up once your goal for the chosen sport is achieved.

Sleep Tracker



the quality of your sleep. Note: Sleep detection starts from 10pm to 8am the next day. Hydration Reminder



Hydration is key to feeling your best so the smart watch will remind you it's time to drink some water at the planned time. Note: You can set the time and days within the app.

If the watch is worn whilst you sleep, it

will keep track of the hours slept and

Step Counter



The watch automatically tracks the number of steps you have taken. Note: Your movement stats reset to 0 at midnight.





Click the music icon to enter the music playback control interface. You can select the previous/next song, as well as play/pause music, increase or decrease volume. To exit the music playback controls, swipe left to right on the screen.

Timer



A countdown timer lets you set goals and time your activities.

OUR GUARANTEE

This smartwatch is produced using premium materials and is fully tested before leaving our manufacturing centre.

Your watch is guaranteed against any defective parts & construction for 2 years from the date of purchase. Your guarantee is only valid if you present your original receipt when returning the item. This guarantee provides you with rights in addition to your consumer statutory rights and therefore does not limit your statutory rights.

Please note this guarantee does not cover lenses, bands, straps or bracelets, water penetration or batteries. Additionally, breakages caused by accident or maltreatment are not covered.

We hope you'll love your watch, but if you do have any problems please contact us and we'll guide you through the guarantee process.

HEALTH WARNINGS

HEALTH WARNINGS HENRY LONDON smartwatches contain components that emit electromagnetic fields, with some of the models containing a magnetic charging dock, please be aware that these models contain magnets. These electromagnetic fields and magnets may interfere with medical devices, such as pacemakers and implanted defibrillators. Please consult your doctor and medical device manufacturer if you use any medical device before using a HENRY LONDON smartwatch. Smartwatches use multitaxis inertial sensors called accelerometers. These detect wrist movement in order to measure steps. However, some wrist actions whilst standing or sitting can mimic the arm movement of a step and can therefore falsely record steps. The step count recorded each day should be used as a guide only.

In the case of material damage or personal injury caused by incorrect handling or non-compliance with the safety instructions, no liability can be accepted by HENRY LONDON. If you have any questions or concerns, please contact us, you'll find our contact details on this leaflet.

PRIVACY POLICY

ase view our privacy policy at : https://henry-london.com/pages/privacy-policy

Manufactured by: Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, B37 7GN, UK. EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

DECLARATION OF CONFORMITY

The original UK and EU declaration of conformity may be found at : https://henry-london/pages/docc

DISPOSAL OF GOODS

The crossed out wheelie bin symbol is to remind you that waste electrical products, batteries & accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic a site or a local authority recycling facility.

・Do not dispose of your HENRY LONDON product within household waste • Disposal of the packaging & your HENRY LONDON product should be done in accordance with local regulations • Batteries are not to be disposed of in municipal waste & require separate collection.

Stopwatch

00-00-25

You can start and stop your stopwatch allowing you to keep track of the timings of your favourite activities

The device will sync incoming

Note: You can select the notifications you

The watch will display the weather

notifications and messages.

wish to receive in the app.

240 when it is connected to the app.

Weather Updates