

## How to Remove and Replace the Inner Pump Tubing on the Eco Clever

### Before starting,

Disconnect the power to the machine and from the rear locate the blue pump on the right,



### What you'll need

Large phillips screwdriver


### Instructions

Twist the head of the pump to the left to remove



Pull away the old tubing and remove the white rotor with 4 yellow wheels attached

Insert the replacement tube into the head of the pump and clip into place. Using a new piece of tubing, slide on the nut then the sleeve then the insert over the new tube and screw tightly onto the new connector



Reinstall the rotor and then push the tube into the gap. You can make this easier by using the screwdriver to turn the rotor

We recommend using some silicone based lubricant on the tube to aid it's longevity



[Watch the Video](#)



[These parts are available through our website here](#)