




POWERDASH™ PET **ADVANCED** CARPET & UPHOLSTERY CLEANER



QUICK START GUIDE

HOW TO USE

1




Remove Clean Water Tank, twist off water cap on bottom and add warm water to the fill line.

2




Add Hoover® cleaning solution to the Solution Fill Line then replace and tighten the cap.

3




Slide the Clean Water Tank back into the unit.

4



Plug power cord into electrical outlet. Step on the Handle Release Pedal to recline the unit into the cleaning position.

5



Step on the ON/OFF Pedal to turn ON.

HOW TO USE (CONT'D)



SQUEEZE TRIGGER
TO WASH


6 Slowly push forward then backwards while squeezing the trigger to apply water and cleaning solution.




RELEASE TRIGGER
TO DRY

7 Release trigger then slowly push forward then backwards to remove water and dry the carpet.


HOW TO USE: ATTACHMENT AND 2-IN-1 TOOL



1 To clean with hose tool remove nozzle cover and plug in firmly.



2 Slide 2-in-1 tool onto hose.



3 Spray and scrub the area, then slowly pull toward you to extract.

EASY CLEANUP AND MAINTENANCE: AFTER EACH USE



1 Remove the tank lid to empty and rinse tank.



2 Remove the Nozzle Cover and rinse.



3 Flip the brushroll window forward to remove any debris from the brushroll.

ALLOW PARTS TO AIR DRY BEFORE STORING.