



TROUBLESHOOTING

Having some issues with your Blazing Bull? Try to resolve them with some of these troubleshooting solutions.
If you are still unable to resolve your issue,

PROBLEM	POSSIBLE CAUSE	SOLUTION
Burners do not ignite	<i>Valve on propane tank is not open</i>	Make sure valve on propane tank is fully open
	<i>Regulator hose is squeezed, bent, or leaking</i>	Check the hose routing and remove obstacles
	<i>Gas isn't getting to the burners</i>	Push and hold down the gas knob in the ON position when pressing igniter button
	<i>No spark occurs when pressing igniter button</i>	Replace igniter battery
	<i>Propane bottle is empty</i>	Refill propane tank at an authorized LP gas dealer
Burner ignites but tiles appear to be more white than orange	<i>Sunlight may affect the appearance of the burner tiles even though the unit is on and operating correctly</i>	Wait 5 minutes for burners to heat up and continue normal usage
Burner tiles remain blue for over 5 minutes	<i>Rain or water may have affected the burner</i>	Allow unit to run for 15-20 minutes and continue usage
Burner extinguishes during operation appear to be more white than orange	<i>Food has touched the safety shut off sensor</i>	Turn unit off, shut off propane tank and lower grill grate. Wait 2-3 minutes, turn on propane tank and re-ignite
	<i>Propane bottle is empty</i>	Refill propane tank at an authorized LP gas dealer
Liner, drawer, or grill grate is stuck in unit	<i>Unit was fired up without inserting all components</i>	Turn off and allow unit to cool down before removing