

パイン材ユニットシェルフ	帆立ワイド	大
パイン材ユニットシェルフ	帆立ワイド	小
パイン材ユニットシェルフ	帆立	大
パイン材ユニットシェルフ	帆立	中
パイン材ユニットシェルフ	帆立	小
パイン材ユニットシェルフ	奥行25cmタイプ	帆立 大
パイン材ユニットシェルフ	奥行25cmタイプ	帆立 中
パイン材ユニットシェルフ	奥行25cmタイプ	帆立 小

Pine unit shelf Frame Wide L

Pine unit shelf Frame Wide S

Pine unit shelf Frame L

Pine unit shelf Frame M

Pine unit shelf Frame S

Pine unit shelf D25 cm Frame L

Pine unit shelf D25 cm Frame M

Pine unit shelf D25 cm Frame S

組立・取扱説明書

User Guide

日本語

この度は本製品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 15.

4550344912157	Pine unit shelf Frame Wide L
4550344912140	Pine unit shelf Frame Wide S
4550344912171	Pine unit shelf Frame L
4550344912188	Pine unit shelf Frame M
4550344912164	Pine unit shelf Frame S
4550344912201	Pine unit shelf D25 cm Frame L
4550344912218	Pine unit shelf D25 cm Frame M
4550344912195	Pine unit shelf D25 cm Frame S

MUJI 無印良品

保存用

パイン材ユニットシェルフ	帆立ワイド	大
パイン材ユニットシェルフ	帆立ワイド	小
パイン材ユニットシェルフ	帆立	大
パイン材ユニットシェルフ	帆立	中
パイン材ユニットシェルフ	帆立	小
パイン材ユニットシェルフ奥行25cmタイプ	帆立	大
パイン材ユニットシェルフ奥行25cmタイプ	帆立	中
パイン材ユニットシェルフ奥行25cmタイプ	帆立	小

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。

ご使用前に本書をよくお読みいただき、内容を理解した上で正しく組み立て、正しくお使いください。

また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～4
パーツリスト	5
各部の名称	5
組立方法	6～10
ご使用方法	11～12
お手入れ方法	12
ご使用に際して	13
製品仕様	14
お問い合わせ先	14

2023 / 10 / 4

重要なお知らせ (安全上のご注意)

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷(※1)を負うことが想定される内容です。



注意

使用者が傷害(※2)を負うことや物的損害(※3)が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。(次は図記号の例です。)



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び、治療に入院、長期の通院を要するものをさします。

※2 傷害とは、治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。

警告



禁止

●フィッティングパーツは幼児の手の届くところには置かないでください。また、なくさないでください。これらは小さく、誤飲してしまうと窒息などのおそれがあります。

●不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。

【組み立てた製品について】

●お子さまに製品に登る、ぶら下がるなどさせないでください。転倒や破損、ケガをするおそれがあります。

●製品の上にのらないでください。バランスをくずして転倒したり、製品の破損によりケガをするおそれがあります。

●上部に重たい物は置かないでください。地震などで物が落ちたり、棚ごと倒れたりして、ケガをするおそれがあります。

●ストーブなど引火するおそれのある物を近くに置かないでください。火災の原因になります。

●製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。



行う

【組み立てた製品について】

●基本セット(※)もしくは、棚板(単品)に付属の組立・取扱説明書をよく読み正しくお使いください。組み立てた製品に対し、お使いになる上での注意が記載されており、ケガを防ぎ、安全にお使いいただくために重要です。

●AV機器を置く場合は、そのAV機器の取扱説明書をよく読み正しく設置してください。また、十分に隙間をあけて通気性をよくしてご使用ください。電気製品の故障や火災の原因となります。

※パイン材ユニットシェルフシリーズの帆立、棚板、クロスバーがセットになった製品。

⚠ 注意



禁止

- 指定の用途以外で使用しないでください。破損してケガをするおそれがあります。
 - 棚板のメタルガイド（端部）を直接触らないでください。指や手を切るおそれがあります。
- 【組み立てた製品について】**
- 製品を連結したままで持ち上げないでください。破損、ケガをするおそれがあります。
 - 物をのせたままで棚板を持ち上げないでください。収納物が破損、ケガをするおそれがあります。
 - 組み立てが不完全なまま使用しないでください。固定部分がはずれてケガの原因になることがあります。
 - 移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。
 - 棚板のメタルガイドは他の家具や壁などに当たらないようにしてください。製品破損やキズ、ケガしたりするおそれがあります。
 - 耐荷重を超えて物をのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損の原因となり、ケガをするおそれがあります。
 - 修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。
 - 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。



行う

- 棚板を取り付ける際、取り付け部周囲に手や指が可動部や隙間に触れないようにしてください。指や手のはさまれて、ケガをするおそれがあります。
 - 組み立ては、大人2人以上で行ってください。1人で作業すると、転倒や破損、ケガをしたり、床をキズつける原因となります。
 - 必要に応じた数の棚板とすべてのクロスバーを取り付けてご使用ください。必要数以下に減らすと強度が低下しケガをする原因となります。
- 【組み立てた製品について】**
- 使い始める時は、室内の換気を十分にしてください。接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状をおこすおそれがあります。
 - 壁から少し離して設置してください。空気の滞留や壁側の結露を防ぎ、カビの発生防止になります。また、壁に直接触れないことで、壁紙の変色防止にもなります。
 - 各部にグラつきや破損がないか定期的に点検し、異常が認められたら使用を中止してください。そのまま使用すると、ケガや破損の原因となります。
 - 本体が破損した場合、直ちに使用を中止してください。破損したまま使用すると、ケガをするおそれがあります。
 - 移動させる際は、収納物を取り除き、大人2人以上で移動させてください。1人で無理に移動させると、破損、ケガをするおそれがあります。
 - 移動をする際は、組み立て前の状態に戻してから運んでください。ケガや製品の破損、床面がキズがつくおそれがあります。

お願い (その他 注意)

- シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。
 - 廃棄の際は、居住地域の自治体のルールに従い、処分してください。
- 【組み立てた製品について】**
- 平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。
 - 高温な場所、乾燥した場所で長期間設置しないでください。製品の反りやゆがみ、割れなどの原因になります。
 - 直射日光や冷暖房器具などの熱や風が製品に直接当たらないようにしてください。反りやゆがみ、割れ、変色などの原因になります。
 - 製品に直接熱い物や濡れた物を置かないでください。反りやゆがみ、割れ、変色、カビなどの原因となります。
 - 棚板の上にビニール製品（塩化ビニル樹脂など）を直接、長期間置かないでください。変色したり、塗装がはがれる原因となります。

パーツリスト

ワイド・大

ワイド・小

大

中

小

奥行25cm・大


奥行25cm・中

奥行25cm・小


共通

※各リストは共通です。

① 帆立 ×1



各部の名称



(完成図)

※イラストには、大を使用しています。

組立方法

ワイド・大

ワイド・小

大

中

小

奥行25cm・大


奥行25cm・中


奥行25cm・小

共通

※組み立て手順は共通です。

※イラストには 大 を使用しています。

 注意	<p>❶ 棚板は、クロスバーを組み立ててから取り付けてください。 先に棚板を取り付けると、組み立て中に棚板が破損する場合があります。</p>
--	--

 注意	<p>❶ 組み立ては、大人2人以上で行ってください。1人で作業すると、転倒や破損、ケガをしたり、床をキズつける原因となります。</p> <p>❷ 組み立てには電動工具は使用しないでください。無理な負荷がかかると、製品破損によりケガをするおそれがあります。</p> <p>❸ 組み立て後、1週間程度経過しましたら、ボルトを締め直してください。使い始めはゆるんでいる場合があり、そのまま使用すると破損、ケガの原因となります。</p> <p>❹ 組み立て時は、組み立てに必要なスペースを十分に確保し、敷物を敷いてください。床や既存の家具のキズ防止になります。</p>
--	--

お願い (その他 注意)	<p>強度を保つために必要なパーツは取り付けて使用してください。</p>
-------------------------	--------------------------------------

※ドライバーは付属されていません。適切なサイズのプラスドライバーをご用意ください。
(ドライバーの先端が大きすぎたり、小さすぎると組み立てが難しい場合があります。)


基本セット(※)に連結する場合

※基本セットとは、パイン材ユニットシェルフの帆立、棚板、クロスバーがセットになった製品のことで。

1 組み立て済みの製品に対して、連結したい側に①帆立を立てて棚板とクロスバーを取り付けてください。組み立て方法については、基本セットに付属の組立・取扱説明書、もしくは次ページの「追加用の単品(棚板、クロスバー)を使って組み立てる場合」を参照し、同じ要領で組み立ててください。


※ ワイド・大 ワイド・小 には、基本セットはありませんので、次ページを参照してください。

完成例



棚板の取付方法

●基本的には棚板の入れ方と同じ組立手順です。まず、棚板を帆立の内側に入れます。その後、メタルガイドを溝に差し込む際に、メタルガイドが差し込まれていない部分を使用します。手前側、奥側の順番でメタルガイドを帆立の横桟にある溝にはめ込みます。



追加用の単品 (棚板、クロスバー) を使って組み立てる場合


1

はじめに組み立てる場所に敷物を敷いて、床面を保護してください。
(組み立て後の移動を避けるため、なるべく設置位置の近くで行ってください。)

- ① ①A帆立の「ガイド穴」の付いた面を上に向けて床に置いてください。また、その際に①A帆立の横棧の溝を2本とも同じ方向に合わせてください。
- ② 次ページの『クロスバー取り付けについて』を参照し、使用する「ガイド穴」の位置を確認してください。
- ③ クロスバーの「取り付け穴」を合わせ、図のようにプラスドライバーを使用してクロスバー用木ネジで固定してください。

※①A帆立の「ガイド穴」は、クロスバー取り付け位置の目安にするための小さな穴です。見落とさないようご注意ください。「ガイド穴」のある方が製品の背面となります。







お願い (その他 注意)	<ul style="list-style-type: none"> ● 帆立の向きに注意してください。 ① 「ガイド穴」を上 に します。 ② 横棧の溝を同じ方向に します。 ● 使用する「ガイド穴」の位置にご注意ください。
お願い (その他 注意)	<p>使用する「ガイド穴」の位置にご注意ください。</p> <p>棚板・86cm幅 棚板・58cm幅 で異なります。</p> <p>詳しくは、次ページの『クロスバー取り付けについて』をご確認ください。</p>



組立方法 (つづき)

クロスバー取り付けについて

取り付ける帆立と棚板のサイズによって、クロスバーの取り付け位置が異なりますのでご注意ください。
 下図にて、使用する「ガイド穴」の位置を確認してください。


帆立・大、 帆立ワイド・大 (高さ175.5cm)、 奥行25cmタイプ・帆立・大 に取り付けする場合	帆立・中 (高さ120cm)、 奥行25cmタイプ・帆立・中、 帆立・小、帆立・ワイド小 (高さ83cm)、 奥行25cmタイプ・帆立・小 に取り付けする場合
<p>ガイド穴の数について ガイド穴が6ヶ所あります。</p>  <p>ガイド穴</p>	<p>ガイド穴の数について ガイド穴が3ヶ所あります。</p>  <p>ガイド穴</p>
<p>クロスバー取り付け位置について</p> <p>棚板・86cm幅 の場合 ①、③、④、⑥を使用します。</p>  <p>ガイド穴②、⑤は 使用しません。</p> <p>棚板・58cm幅 の場合 ①、②、⑤、⑥を使用します。</p>  <p>ガイド穴③、④は 使用しません。</p>	<p>クロスバー取り付け位置について</p> <p>棚板・86cm幅 の場合 ①、③を使用します。</p>  <p>ガイド穴②は 使用しません。</p> <p>棚板・58cm幅 の場合 ②、③を使用します。</p>  <p>ガイド穴①は 使用しません。</p>

組立方法 (つづき)

※イラストには 大 を使用しています。

2

図のように床から起こしたら、次にクロスバーのついた側が背面になるように置いてください。また、その際①帆立の横棧の溝を上側に向けてください。



3

「棚板の入れ方」を参考に、下段から設置する棚板を取り付けます。※収納する物の高さに応じて棚板の取り付け位置を決めてください。

棚板の入れ方

- ① まず、正面から棚板を斜めにして2本の帆立の間を通します。
- ② 手前側のメタルガイドを帆立の横棧にある溝にはめ込みます。
- ③ 奥側のメタルガイドも同様に溝にはめ込みます。
※少し力を入れてはめ込んでください。

注意


- ⊗ メタルガイドの端部を素手で触らないでください。ケガをするおそれがあります。
- ⊗ 棚板を取り付ける際、取り付け部（帆立の端とメタルガイド）の周囲に指や手を置かないでください。指や手をはさみケガをするおそれがあります。

組立方法 (つづき)



※イラストには 大 を使用しています。

4

すべての棚板がしっかり固定されているか確認してください。



完成

 警告	⊘ 帆立や棚板によじ登ったりぶら下がったりしないでください。製品の転倒や破損によりケガをするおそれがあります。
 注意	棚板の取り付け枚数と位置にご注意ください。下記を守らないと強度が低下し、破損によるケガの原因となります。 ❗ 帆立の一番上と一番下には棚板を取り付けてください。

全体耐荷重について

下表の耐荷重を守ってお使いください。

※棚板1枚の耐荷重は、棚板（単品）に付属の組立・取扱説明書を参照してください。

	棚板の幅サイズ	
	幅86cmタイプ	幅58cmタイプ
帆立・大、帆立ワイド・大(高さ175.5cm)	約100kg	約80kg
帆立・中(高さ120cm)	約75kg	約60kg
帆立・小、帆立・ワイド小(高さ83cm)	約50kg	約50kg
奥行25cmタイプ・帆立・大(高さ175.5cm)	約50kg	約40kg
奥行25cmタイプ・帆立・中(高さ120cm)	約30kg	約30kg
奥行25cmタイプ・帆立・小(高さ83cm)	約25kg	約25kg

ご使用方法

使用する棚板とクロスバーの必要数について



● 安全にご使用いただくため、棚板の取り付け枚数と取り付け位置をお守りください。

● 棚板とクロスバーは、帆立のサイズに応じた必要数を使用してください。

棚板

大サイズ…3枚以上
中サイズ…3枚以上
小サイズ…2枚以上


クロスバー

大サイズ…2つ
中サイズ…1つ
小サイズ…1つ


● 帆立の一番上と一番下の位置には、必ず棚板を使用してください。




正しい使い方の例



一番上と一番下の位置に棚板を使用していない例



棚板の数が必要数に足りていない例



※イラストは、帆立・大サイズを使用しています。


収納する際のご注意



○ 上部に重たい物は置かないでください。地震などで物が落ちたり、棚ごと倒れたりして、ケガをするおそれがあります。



不安定になりやすい使い方（例）



ご使用方法（つづき）

移動について

〈組み立てた状態で動かす場合〉

- 移動させる際は、収納物を取り除き、大人2人以上で左右から帆立部分をしっかり持って移動させてください。1人で無理に移動させると、破損、ケガをするおそれがあります。
- 物をのせたままで棚板を持ち上げないでください。収納物が破損、ケガをするおそれがあります。
- 移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。

〈引越しなどで運ぶ場合〉

- 移動をする際は、組み立て前の状態に戻してから運んでください。ケガや製品の破損、床面がキズがつくおそれがあります。

廃棄について

- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お手入れ方法

保守・点検

- 破損や変形した状態では使用しないでください。
- 各部にグラつきや破損がないか定期的に点検し、異常が認められたら使用を中止してください。そのまま使用すると、ケガや破損の原因となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

木部のお手入れ

- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。

金属部のお手入れ

- 通常のお手入れは、やわらかい布で乾ぶきしてください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。

ご使用に際して

天然木製品について

- 本製品は天然木を使用しているため、製品ごとに天然木材特有の個体差（木目や色合いなど）がありますが、あらかじめご了承ください。
- 天然木は下記の条件により、割れや反りなどが発生するおそれがありますので、ご注意ください。
 - ・直射日光の当たる場所でのご使用は出来る限りお避けください。
どうしても直射日光が当たる場合は、カーテンなどで出来る限り避けてご使用ください。
 - ・冷暖房器具の近くでのご使用は出来る限り避け、必ず冷暖房の風が直接当たらないようにしてください。
 - ・特に冬の暖房による室内の極端な乾燥は、天然木の割れ、反りを発生させる原因となります。

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しづつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気について



- ❶ 家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率を上げるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。

アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

製品仕様

パイン材ユニットシェルフ・帆立ワイド

品名	パイン材ユニットシェルフ 帆立ワイド 大	パイン材ユニットシェルフ 帆立ワイド 小
J A N	4550344912157	4550344912140
製品寸法	幅500×奥行30×高さ1755 (mm)	幅500×奥行30×高さ830 (mm)
製品質量	約 2.3 kg	約 1.2 kg
用途	パイン材ユニットシェルフ用帆立	
材質	帆立 : 天然木 (パイン材) 表面加工 : アクリル樹脂UV塗装	
原産国	中国	

パイン材ユニットシェルフ・帆立

品名	パイン材ユニットシェルフ 帆立 大	パイン材ユニットシェルフ 帆立 中	パイン材ユニットシェルフ 帆立 小
J A N	4550344912171	4550344912188	4550344912164
製品寸法	幅395×奥行30×高さ1755 (mm)	幅395×奥行30×高さ1200 (mm)	幅395×奥行30×高さ830 (mm)
製品質量	約 2.1 kg	約 1.5 kg	約 1 kg
用途	パイン材ユニットシェルフ用帆立		
材質	帆立 : 天然木 (パイン材) 表面加工 : アクリル樹脂UV塗装		
原産国	中国		

パイン材ユニットシェルフ 奥行 25cm タイプ・帆立

品名	パイン材ユニットシェルフ 奥行25cmタイプ 帆立 大	パイン材ユニットシェルフ 奥行25cmタイプ 帆立 中	パイン材ユニットシェルフ 奥行25cmタイプ 帆立 小
J A N	4550344912201	4550344912218	4550344912195
製品寸法	幅260×奥行30×高さ1755 (mm)	幅260×奥行30×高さ1200 (mm)	幅260×奥行30×高さ830 (mm)
製品質量	約 1.75 kg	約 1.25 kg	約 0.8 kg
用途	パイン材ユニットシェルフ用帆立		
材質	帆立 : 天然木 (パイン材) 表面加工 : アクリル樹脂UV塗装		
原産国	中国		

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ

 0120-14-6404

Pine unit shelf Frame Wide L
Pine unit shelf Frame Wide S
Pine unit shelf Frame L
Pine unit shelf Frame M
Pine unit shelf Frame S
Pine unit shelf D25 cm Frame L
Pine unit shelf D25 cm Frame M
Pine unit shelf D25 cm Frame S

User Guide

Thank you for your purchase.

Read this User Guide before use to ensure correct assembly and use of the product.

Store this guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	16 - 18
Parts	19
Part Names	19
Assembly Instructions	20 - 24
Directions for Use	25 - 26
Care Instructions	26
General Notes	27
Specifications	28
Contact Information	28

Important Information (Safety Advice)



The instructions must be followed.

This User Guide contains important information for safe use of the product in order to prevent harm to users and other individuals as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this guide and follow the given instructions.

- Explanations of Indications

The extent of injury and damage that may arise when the product is used incorrectly is classified and explained with the following symbols.

 WARNING Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury* ¹ to the user.	 CAUTION Indicates a hazard with a level of risk which, if not avoided, could result in injury* ² to the user or property damage* ³ .
---	--

- Explanations of Graphic Symbols



Instructions are given in the form of the following graphic symbols. (Examples of graphic symbols are as follows.)

 Actions that are prohibited.	 Actions that must be taken.
--	---

*1 "Serious injury" indicates injuries, such as blindness, traumas, burns, bone fractures, poisoning, or electric shocks, that have long-term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates traumas or burns that do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates extended damage that involves the house or household property.

 WARNING	
 DON'Ts	<ul style="list-style-type: none"> • Do not keep the fitting parts within reach of small children and be careful not to lose them. Small parts may cause accidental swallowing and choking. • Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate. <p>[About Assembled Products]</p> <ul style="list-style-type: none"> • Do not let children climb on or hang from the product. Doing so may cause tip-over, damage and/or injury. • Do not climb on the product. Doing so may cause tip-over from loss of balance or product damage and may lead to injury. • Do not place anything heavy in the upper section. The object may fall or the product may tip over resulting in injury in the event of an earthquake, etc. • Do not place near a heat source such as a heater. Doing so may cause a fire. • Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.

WARNING (Continued)



DOs

[About Assembled Products]

- Carefully read the User Guide provided with basic shelf set* or additional frame (sold separately), to ensure correct use. It contains precautions for using the assembled product to help prevent injury and ensure your safety.
- When placing an AV equipment on the product, carefully read the instructions of the equipment, and install properly leaving some space for ventilation. Failure to do so may cause malfunction of the equipment or a fire.

* Set product in the pine unit shelf series that includes frames, shelf boards and cross bars.

CAUTION



DON'Ts

- Do not use for other than its intended purpose. Doing so may cause damage to the product, resulting in injury.
- Do not directly touch the edge of the metal guides on the shelf boards. Doing so may cause cuts to your fingers or hands.

[About Assembled Products]

- Do not lift the products when they are connected. Doing so may cause product damage and/or injury.
- Do not lift the shelf board(s) with anything placed on top. Doing so may cause injury and/or damage to the stored items.
- Do not use unless fully assembled. Doing so may cause the fixed parts to come off and lead to injury.
- Do not drag when moving the product. Doing so may cause product damage, floor scratches and/or injury.
- Be careful not to allow the metal guides to come in contact with other furniture or the wall. Failure to do so may cause product damage, scratches and/or injury.
- Do not place anything exceeding the withstand load or anything only on one side even if it is within the withstand load. Doing so may cause product deformation or damage and lead to injury.
- Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury.
- Do not use outdoors. Doing so may cause deformation or severe degradation, leading to injury.

CAUTION (Continued)



DOs

- When installing shelf boards, be careful not to put your hands or fingers near the installation parts, moving parts and gaps. Doing so may cause your hands or fingers to get caught and injured.
- The product must be assembled by at least two adults. Assembling alone may cause injury, tip-over, damage and/or floor scratches.
- Attach the required number of shelf boards and all cross bars. Using less than the required number reduces the strength of the product, which may result in injury.

[About Assembled Products]

- Ventilate the room well at the early stage of use. Formaldehyde contained in adhesive may still remain, and those with chemical sensitivity and small children may experience allergic reactions.
- Install slightly away from the wall. This is to prevent air stagnation and condensation on the wall, and eventually mould growth. Avoiding direct contact with the wall also prevents discolouration of the wall paper.
- Regularly check for any looseness or damage in all parts, and stop use if any abnormalities are found. Continued use under this condition may cause injury or product damage.
- Immediately stop use if damaged. Continued use of the damaged product may cause injury.
- When relocating the product, remove all stored items and be sure to move it with at least two adults. Moving it alone may result in damage and/or injury.
- When relocating the product, put it back into the pre-assembly state beforehand. Not doing so may cause injury, product damage or scratches on the floor.

Note (Other Caution)

- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- To dispose of the product, follow the rules implemented by your local government.


[About Assembled Products]

- Install on a flat and stable surface. Using on an unstable surface may cause product distortion or damage.
- Do not place in locations with high temperatures or low humidity for a long time. Doing so may cause warping, distortion or cracking.
- Do not expose to direct sunlight and heat or air from heating and cooling appliances. Doing so may cause warping, distortion, cracking, or discolouration.
- Do not place hot or wet items directly on the product. Doing so may cause warping, distortion, cracking, discolouration or mould growth.
- Do not place plastic items (vinyl chloride resin, etc.) directly on the shelf boards for a long time. Doing so may cause discolouration or peeling of the coating.


Parts

D25 CM FRAME L **D25 CM FRAME M** AND **D25 CM FRAME S**

* Each list applies to all models.




Part Names




Assembly Instructions D25 CM FRAME L D25 CM FRAME M AND D25 CM FRAME S

* Assembly instruction is common to all the models.

* L is used in the illustrations.

 CAUTION	<p>❗ Attach the cross bars before installing the shelf boards. Installing the shelf boards before attaching the cross bars may cause damage to the shelf boards during assembly.</p>
---	--

 CAUTION	<p>❗ The product must be assembled by at least two adults. Assembling it alone may cause injury, tip-over, damage and/or floor scratches.</p> <p>⚠ Do not use power tools to assemble the product. Placing excessive strain on the product may cause damage and lead to injury.</p> <p>❗ Retighten all the bolts approximately one week after assembly. They may be loose at the start of use, and continued use under this condition can lead to damage and/or injury.</p> <p>❗ Secure enough space and place an underlay when assembling the product. This prevents the floor and other furniture from scratches.</p>
---	---

Note (Other Caution)	<p>Use the product with the necessary parts attached for maintaining strength of the product.</p>
---------------------------------	---

* Screwdriver is not included. Prepare your own cross-head screwdriver of a suitable size.
(It may be difficult to assemble the product if the screwdriver head is too large or too small.)


When connecting to a basic shelf set (*)

* Set product in the pine unit shelf series that includes frames, shelf boards and cross bars.

1 Stand A frame on the side of the assembled product that you want to connect it to, and then attach the shelf boards and cross bars. For details on how to assemble the product, refer to the User Guide provided with the shelf set, or "Assembling an Additional Single Product (Additional Shelf Board, Crossbar)" on the following page and assemble it in the same procedure.



* There is no set product for WIDE L and WIDE S. Refer to the following page.

Completion Example



How to Attach a Shelf Board

• This process is basically the same as inserting the shelf boards. First, place the shelf board inside the frame. Next, insert the metal guides into the grooves that do not yet have a metal guide inserted. Insert the front metal guides into the slots on the horizontal rung, then insert the back metal guides.



Assembling an additional product (Shelf Board, Crossbar)


1 Place a protective underlay on the floor where the product will be assembled.
(Assemble the product as close to the installation location as possible to reduce the need to move the product after assembly.)

- ① Place A frames on the floor with the guide holes facing up. Make sure that the grooves on the horizontal rungs of both A frames face the same direction.
- ② Refer to "Attaching Cross Bars" on the following page, and locate the position of the guide holes to be used.
- ③ Align the installation holes of the cross bars with the guide holes, and fix the cross bars in place with a wood screws using a cross-head screwdriver as shown in the figure.

* The guide holes of A frame are the small holes used as a guide for positioning the cross bar. Be careful not to miss them. The side with the guide holes is the back of the product.

Note (Other Caution)	<ul style="list-style-type: none"> • Make sure the frames are facing in the correct orientation. <ol style="list-style-type: none"> ① The guide holes face upwards. ② Grooves on the horizontal rungs face in the same direction. • Make sure to use the right guide holes.
--------------------------------	--







Note (Other Caution)	<p>Make sure the positions of the guide holes to be used are correct. The positions differ between SHELF BOARD / W86 CM and SHELF BOARD / W58 CM. See "Attaching Cross Bars" on the following page for details.</p>
--------------------------------	---



Assembly Instructions (Continued)

Attaching Cross Bars

Note that the attachment position of the cross bars differs depending on the size of frame and shelf board. Locate the guide holes referring to the figures below.


Attaching to "FRAME / L", "WIDE TYPE / FRAME / L (H175.5 CM)" or "D25 CM / FRAME / L"	Attaching to "FRAME / M (H120 CM)", "D25 CM / FRAME / M", "FRAME / S", "WIDE TYPE / FRAME / S (H83 CM)" or "D25 CM / FRAME / S"
<p>Number of Guide Holes</p> <p>There are 6 guide holes.</p> 	<p>Number of Guide Holes</p> <p>There are 3 guide holes.</p> 
<p>Position of Cross Bars</p> <p>In case of SHELF BOARD W86 CM Guide holes ①③④ and ⑥ are used.</p>  <p>In case of SHELF BOARD W58 CM Guide holes ①②⑤ and ⑥ are used.</p> 	<p>Position of Cross Bars</p> <p>In case of SHELF BOARD W86 CM Guide holes ① and ③ are used.</p>  <p>In case of SHELF BOARD W58 CM Guide holes ② and ③ are used.</p> 

Assembly Instructions (Continued)

* L is used in the illustrations.

2

As shown in the figure, stand the product upright and place it with the side with the cross bars at the back. Make sure that the grooves on the horizontal rungs of A frames are facing up.





3

Refer to "Inserting Shelf Boards", and install the shelf boards starting from the bottom shelf.

* Install the shelf boards according to the height of items to be stored.

Inserting Shelf Boards

- ① Insert the shelf board diagonally from the front between the two frames.
 
- ② Insert the metal guides of the front side into the groove of the horizontal rung.
 ③ Insert the metal guides of the back side into the grooves in the same way.


* Push firmly when inserting the metal guides.
 

Metal Guide


CAUTION


- ⊘ Do not touch the edges of the metal guides with bare hands. Otherwise it may cause injury.
- ⊘ Do not hold any areas around the frame edges or metal guides when installing the shelf boards. Doing so may cause your hands and fingers to get caught, resulting in injury.

Assembly Instructions (Continued)



*  is used in the illustrations.

4

Check that all of the  shelf boards are fixed securely in place.



Completed

 WARNING	<p>⊘ Do not climb on or hang on the frame or shelf boards. Doing so may cause damage to the product, resulting in injury.</p>
 CAUTION	<p>Make sure the number and the positions of the shelf boards are correct. Failure to follow the instructions below will reduce the strength of the product, which may result in injury due to damage of the product.</p> <p>⚠ Be sure to install shelf boards to the top and the bottom of the frame.</p>

Withstand load


Use within the withstand load referring to the chart below.

* As for withstand load of each shelf board, see the User Guide provided with Shelf Board.

	Width of Shelf board	
	W86 cm type	W58 cm type
FRAME / L, WIDE TYPE / FRAME / L (H175.5 CM)	Approx. 100 kg	Approx. 80 kg
FRAME / M (H120 CM)	Approx. 75 kg	Approx. 60 kg
FRAME / S, WIDE TYPE / FRAME / S (H83 CM)	Approx. 50 kg	Approx. 50 kg
D25CM / FRAME / L (H175.5 CM)	Approx. 50 kg	Approx. 40 kg
D25CM / FRAME / M (H120 CM)	Approx. 30 kg	Approx. 30 kg
D25CM / FRAME / S (H83 CM)	Approx. 25 kg	Approx. 25 kg

Directions for Use

Required Number of Shelf Boards and Cross Bars

 CAUTION	<p>! In order to use this product safely, be sure to install the correct number of shelf boards in the correct positions.</p>
---	--

- Use the required number of shelf boards and cross bars according to the frame size.

Shelf Board


Large Size3 or more
 Medium Size.....3 or more
 Small Size2 or more


Cross Bar


Large Size2
 Medium Size..... 1
 Small Size 1


- Be sure to install the shelf boards on the top and bottom of the frame.


 Example: Correct Use



 Example: When there is no shelf board on the topmost and bottommost shelf.





 Example: When the number of the shelf boards is insufficient




* FRAME / L is used in the illustrations.

Cautions for Storage

 CAUTION	<p>! Do not place anything heavy in the upper section. The object may fall or the product may tip over, resulting in injury in the event of an earthquake, etc.</p>
---	--

 Unstable Usage (Example)



Directions for Use (Continued)

Relocating the Product

<Relocating the Fully Assembled Product>

- When relocating the product after assembly, remove all stored items beforehand. The product must be moved by two or more people holding the frames firmly from both sides. Moving it alone may result in damage and/or injury.
- Do not lift the shelf board with anything placed on it. Otherwise this may cause injury and/or damage to the stored items.
- Do not drag the product. Doing so may cause product damage, floor scratches and/or injury.

<Relocating the Product for a Home Move, etc.>

- When moving the product, put it back into the pre-assembly state beforehand. Not doing so may cause injury, product damage or scratches on the floor.

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Care Instructions

Maintenance and Inspection

- Do not use if damaged or deformed.
- Regularly check for any looseness or damage in all parts, and stop use if any abnormalities are found. Continued use under this condition may cause injury or product damage.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Maintenance for Wooden Parts

- Gently wipe off dust from coated surfaces using a soft cloth or duster.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.

Maintenance for Metal Parts

- For regular cleaning, wipe with a soft, dry cloth.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.

General Notes

Care Tips for Natural Wood Products


- As this product is manufactured using natural wood, there are individual differences (grain, colour, etc.) unique to natural wood.
- Note that cracking and warping may occur in natural wood (veneer) under the following conditions.
 - Avoid use at locations exposed to direct sunlight. If exposure to direct sunlight is unavoidable, use curtains, etc. to reduce the amount of sunlight.
 - Avoid use near heaters or air conditioners and make sure that the air from heater or air conditioner does not come into direct contact with the product.
 - In particular, use of heating appliances during winter causes the room to become extremely dry and may lead to cracking or warping of natural wood.

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be a cause of sick house syndrome. It is a colourless, pungent-smelling chemical that vaporises at room temperature, often found in furniture, building materials, wallpaper adhesives, etc. As it is gradually released into the air, spending a long time in a room contaminated with formaldehyde can result in eye/throat irritation. Also, exposure to a high concentration of formaldehyde may cause breathing difficulties.

- Room Ventilation

 CAUTION	● ! Ventilate the room well when installing the furniture. Some individuals sensitive to chemicals and small children may experience allergic symptoms.
---	--

Be sure to frequently ventilate the room on a regular basis as formaldehyde is released into the air. Especially when installing multiple pieces of furniture at the same time, open the windows wide enough to allow adequate ventilation. Formaldehyde release tends to increase with temperature rise of the room. Therefore, be sure to ventilate well after the room has been closed up for a long time during summer. It is recommended that you open multiple windows and use a ventilation fan or an air circulator to increase ventilation efficiency.

- For Individuals Sensitive to Chemicals

There are individual differences in resistance to chemicals that are related to sick house syndrome other than formaldehyde. Therefore, even if the actual concentration in the room is lower than the indoor concentration guideline value (acceptable safe level of formaldehyde indoors), some people may react to formaldehyde. MUJI furniture are made with materials that contain as little formaldehyde as possible, but note this does not guarantee that they are completely formaldehyde-free. It is recommended that you seek medical attention if you experience any allergic symptoms.

- Formaldehyde Adsorption/Decomposition Sheet

Formaldehyde is reabsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.

* The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

Specifications

Pine unit shelf Frame Wide

Product Name	Pine unit shelf Frame Wide L	Pine unit shelf Frame Wide S
JAN	4550344912157	4550344912140
Product Dimension	W500 × D30 × H1755 (mm)	W500 × D30 × H830 (mm)
Product Weight	Approx. 2.3 kg	Approx. 1.2 kg
Usage	Frame for Pine Unit Shelf	
Material	Frame : Natural Wood (Pine) Surface Finish : Acrylic Resin UV Coating	
Place of Origin	CHINA	

Pine unit shelf Frame

Product Name	Pine unit shelf Frame L	Pine unit shelf Frame M	Pine unit shelf Frame S
JAN	4550344912171	4550344912188	4550344912164
Product Dimension	W395 × D30 × H1755 (mm)	W395 × D30 × H1200 (mm)	W395 × D30 × H830 (mm)
Product Weight	Approx. 2.1 kg	Approx. 1.5 kg	Approx. 1 kg
Usage	Frame for Pine Unit Shelf		
Material	Frame : Natural Wood (Pine) Surface Finish : Acrylic Resin UV Coating		
Place of Origin	CHINA		

Pine unit shelf D25 cm Frame

Product Name	Pine unit shelf D25 cm Frame L	Pine unit shelf D25 cm Frame M	Pine unit shelf D25 cm Frame S
JAN	4550344912201	4550344912218	4550344912195
Product Dimension	W260 × D30 × H1755 (mm)	W260 × D30 × H1200 (mm)	W260 × D30 × H830 (mm)
Product Weight	Approx. 1.75 kg	Approx. 1.25 kg	Approx. 0.8 kg
Usage	Frame for Pine Unit Shelf		
Material	Frame : Natural Wood (Pine) Surface Finish : Acrylic Resin UV Coating		
Place of Origin	CHINA		

Contact Information

For enquiries regarding the product, please contact the store of purchase.