

## **Hard Reset Procedure:**

1. Unplug the control box.
2. Unscrew the 4 screws holding the clear cover of the WEC3 controller in place.
3. Push and hold the black button in the center of the controller while plugging in the control box again.
4. Continue holding the black button for 5 seconds after the control board has been plugged in, then release the button.
5. Wait about 30 seconds for the controller to reset.