



1. Dial

The watch supports dialing function. When you need to make a phone call, you can enter the number on the watch → Keypad to make calls;

Note: when using this function, you need to keep: ① The phone APP and the watch connected normally; ② BT function of the phone and that of the watch connected normally. (Please refer to the User Manual for connection operation)

Operation instructions

- ① Short press the power button, select "Dial" in the function list.
- ② Enter the phone number in the dialing interface, then press  to make a call.



2. Frequent Contacts

The watch supports Frequent Contacts function. After adding a frequent contact number on the phone APP, you can select the contact on the watch to make a call with just one click, there's no need to dial on the keypad again.

Note: when using this function, you need to keep: ① The phone APP and the watch connected normally; ② BT function of the phone and that of the watch connected normally. (Please refer to the User Manual for connection operation)

Operation instructions

- ① Open FitCloudPro APP, select "Device→Frequent Contacts→Add".
- ② Short press the power button, select "Frequent Contacts" in the function list.
- ③ Click the desired frequent contact to make a call to it.

3. Call Records

The watch supports call record search function. In the Call Records, you can check the recent call records (including incoming, outgoing and missed calls). When you click any one of them, you can call it back.

Operation instructions


- ① Short press the power button, select "Call Records" in the function list.
- ② Swipe up or down to view the call records, click a desired record to make a call to it.

4. Voice Assistant

The watch supports Voice Assistant function. You can click the Voice Assistant on the watch to wake up Voice Assistant of the phone.

Note: when using this function, you need to keep: ① The phone APP and the watch connected normally; ② BT function of the phone and that of the watch connected normally. (Please refer to the User Manual for connection operation)

Operation instructions

- ① Short press the power button, select "Voice Assistant" in the function list.
- ② Click , then you can give commands to your watch, for example, "What's the weather like today?"

5. Message Notifications

The watch can synchronously receive calls and text messages sent to the phone, as well as messages sent to application software as Wechat, QQ, Facebook, Twitter, Instagram, Skype, WhatsApp, Line, Kakao Talk etc., and prompt you by vibration.

Note: When using this function, it is necessary to keep the phone APP and the watch connected normally.

Operation instructions

① Open FitCloudPro APP, select "Device→ Message Notifications" and turn on related push notifications.

② When there is a new message notification on the phone, the watch will prompt you by vibration. You can swipe up on the Home Page of the watch to enter the Unread Message Center and check the unread message.

6. Music Control

The watch supports Music Control function. You can operate on the watch to control music on the phone, such as pause, play, skip to previous/next song and adjust volume.

Note: when using this function, you need to keep: ① The phone APP and the watch connected normally; ② BT function of the phone and that of the watch connected normally. (Please refer to the User Manual for connection operation)

Operation instructions

① Short press the power button, select "Music" in the function list.

② Open the music APP on your phone and play music.





③ In the music playing interface, you can click the watch screen to control music on

the phone, such as pause, play, skip to previous/next song and adjust volume.

7. Stopwatch

The watch supports complete timing and segmented timing operation. For segmented timing, the watch can store up to 10 records.




Operation instructions

- ① Short press the power button, select "Stopwatch" in the function list.
- ② Click  to start counting.
- ③ Click  to record the time in segments. After clicking Pause, click it again to check the segmented records.
- ④ Click  to pause the stopwatch, and click  to reset it.

8. Timer

The watch supports specifying time length and customizing timer operation.

Operation instructions

- ① Short press the power button, select "Timer" in the function list.
- ② Select time length as needed, click  to start the timer.
- ③ Click  to pause the stopwatch, and click  to reset it.

Customizing timer

- ① Short press the power button, select "Timer" in the function list.
- ② Swipe up/down on the Timer Page, click Customize.
- ③ After setting Hour, Minute and Second, click Confirm to realize Timer customization.

9. Alarm

The watch supports alarm reminder function. After setting an alarm on the APP, the watch will remind you on time by vibration.

Operation instructions

- ① Open FitCloudPro APP, click "Device→ Watch Alarm→+ (in the top right corner)", and you can set the time and repeat cycle of the alarm as needed.
- ② After setting successfully, click "Save" in the top right corner.

Turn off and delete Alarm

- ① Open FitCloudPro APP, click "Device→ Watch Alarm→Existing Alarm→" to turn off the alarm.
- ② Enter the "Existing Alarm→Delete Alarm" to delete the alarm.

10. Settings

In Settings, you can customize the watch menu style, screen display, language switch, unlock password, etc.

(1) Menu style switch

Operation instructions

- ① Short press the power button, select "Settings→Menu Style" in the function list.
- ② After selecting the desired menu style, click it again, the menu style will be set successfully.

(2) Screen display

Operation instructions

- ① Short press the power button, select "Settings→Screen Display" in the function list.
- ② In this interface, you can adjust the dial style, screen brightness, auto-lock time and tilt auto-lock time as needed.

(3) Language Switch

The watch supports switching between 10 languages, including Chinese, English, German, Russian, Spanish, Portuguese, French, Japanese, Italian and Polish.

The mobile phone supports simultaneous

upgrading of 27 languages, including: Chinese, traditional Chinese, English, German, French, Italian, Spanish, Japanese, Polish, Russian, Portuguese, Korean, Vietnamese, Arabic, Hebrew, Thai, Croatian, Turkish, Czech, Dutch, Indonesia, Malaysia, Finnish, Greek, Romanian, Hindi and Persian.

Operation instructions (watch)

- ① Short press the power button, select "Settings→Language" in the function list.
- ② Swipe up or down to select the desired language, ✓ indicates the currently set language.

Note: This setting only changes the language on the watch. If you need to synchronize it to the phone, please conduct the following operation steps on the phone:

Operation instructions (phone)

- ① Change language in phone Settings.
- ② Open FitCloudPro APP on the phone, make wireless connection with the watch (For detailed connection steps, refer to User Manual).
- ③ After connecting successfully, the watch language will automatically change with the phone system.

Note: If the phone APP and the watch are already connected, please open the

FitCloudPro APP and refresh it after the mobile phone switches languages.

(4) Unlock Passcode

You can set an Unlock Passcode on the watch to protect your privacy.

Operation instructions

① Short press the power button, select "Settings→Passcode→Turn Passcode On" in the function list. After setting the password successfully, when the watch screen is locked, you need to enter the password to unlock it.

② The Unlock Passcode can also be turned off according to above operations.

11. Find My Watch & Find My Phone

① Click "Find My Watch" function on the phone APP. After finding the watch, the watch will prompt you by vibration, so that you can find it.

② Or click "Find My Phone" function on the watch. After finding the phone, the phone will prompt you by ringtone, so that you can find it.

12. Shake to Take Pictures

Click "Shake to Take Pictures" on the phone APP, a photography icon will appear on the watch. When you shake your wrist, you can count down to take a picture.

Note: When using this function, you need to keep the phone APP and the watch connected normally.

Operation instructions

- ① Wear the watch properly on your wrist.
- ② Open FitCloudPro APP, select "Device→ Shake to Take Pictures", click to enter the function.
- ③ Shake your watch, the phone will show a 3-second countdown, after that, it will prompt photography success.