

MANUAL

DIFFUSER




LOVE AT FIRST SCENT

PLEASE READ BEFORE USE



Do not pour oil into diffuser.
Always keep upright.
Tilting machine will cause damage.

GETTING SET UP



①

Pull out the diffuser head.



②


Unscrew the bottle and fill with desired oil fragrance.

NOTE: Do not fill till to top to avoid leakage.



③


Guide the tubes into the bottle, and screw the bottle into the diffuser head.



④


Insert the diffuser head and bottle into the unit.

NOTE: Make sure the plate is flush with the machine.



⑤

Plug in unit to outlet. Make sure the unit is always upright to avoid leakage.





⑥


Turn on the switch.

S CONNECTING TO APP - BLUETOOTH

Open the “Google Play” store or “App Store” on your smartphone, search for the **Scentify** app and download.



1. Open the Scentify app and select Bluetooth.
2. Select your device.
3. Enter the default password **8888** and press Login.



On the Device Control page;

4. You can change your device name and label information of your scent diffuser.

NOTE: Press the “Save” button at the top right corner of the screen after each change.

5. Press the schedule you would like to edit.

NOTE: You can set up to 5 different schedules by pressing the + button. To delete a schedule, swipe left. Press the toggle button to turn on/off any schedule.



On the “Working period setting” page;

6. Set the hours of the day you want your diffuser to run by scrolling the “Start working time” and “Stop working time”.

7. Select the days of the week you want your diffuser to run (all days are pre-selected).

8. Press + or - to increase or decrease the preset intensity grades (1-20). See chart for details.

9. Check (✓) the Custom box to create a custom intensity and scroll the “Spray Time” and ‘Pause Time”.

NOTE: Press the “Save” button to update the settings.



11. You can change the default password by pressing on the “About” tab, in the “Device control” page.

WARNINGS

Always keep the diffuser upright. Tilted or angled will cause oil to overflow and damage the diffuser.

EQUIPMENT CLEANING

1. Fill the bottle with water-vinegar or rubbing alcohol.
2. Let the diffuser run for about 3-5 minutes.

RESET APP PASSWORD TO 8888


Press C on the device for 6 seconds.

MAINTENANCE & STORAGE



- Always turn off or unplug the diffuser when not in use. Do not move the diffuser while in use.

S CONNECTING TO APP - WIFI

Open the “Google Play” store or “App Store” on your smartphone, search for the **Scentify** app and download.




1. Select Wifi.
2. Login to your account or set up a new account.
3. Select your wifi network and enter the wifi password.
NOTE: Make sure your phone is connected to the same wifi network.
NOTE 2: Only compatible with 2.4ghz wifi.
4. Press Add Device
5. Select your device.
6. On the main page, select your device to change the settings.



On the Device Control page;

7. You can change your device name and label information of your scent diffuser.
NOTE: Press the “Save” button at the top right corner of the screen after each change.
8. Press the power button to turn on/off the diffuser.
9. If after some time, the oil level isn't accurate, press calibrate.
10. Press the schedule you would like to edit.
NOTE: You can set up to 5 different schedules by pressing the + button. To delete a schedule, swipe left. Press the toggle button to turn on/off any schedule.



On the “Working period setting” page;

11. Set the hours of the day you want your diffuser to run by scrolling the “Start working time” and “Stop working time”.
12. Select the days of the week you want your diffuser to run (all days are pre-selected).
13. Press + or - to increase or decrease the preset intensity grades (1-20). See chart for details.
14. Check (✓) the Custom box to create a custom intensity and scroll the “Spray Time” and “Pause Time”.
NOTE: Press the “Save” button to update the settings.

INTENSITY AND OIL CONSUMPTION

Intensity	Spray Time	Pause Time
G1	15 Seconds	300 Seconds
G2	15 Seconds	150 Seconds
G3	20 Seconds	200 Seconds
G4	20 Seconds	85 Seconds
G5	25 Seconds	80 Seconds
G6	30 Seconds	75 Seconds
G7	30 Seconds	60 Seconds
G8	30 Seconds	50 Seconds
G9	30 Seconds	40 Seconds
G10	30 Seconds	33 Seconds
G11	33 Seconds	30 Seconds
G12	40 Seconds	30 Seconds
G13	50 Seconds	30 Seconds
G14	60 Seconds	30 Seconds
G15	75 Seconds	30 Seconds
G16	80 Seconds	25 Seconds
G17	85 Seconds	20 Seconds
G18	120 Seconds	20 Seconds
G19	150 Seconds	15 Seconds
G20	300 Seconds	15 Seconds

TROUBLESHOOTING

Problem	Solution
No Diffusion	<ul style="list-style-type: none">- Check if the power is ON or OFF.- Check if diffuser head is inserted correctly.- Check oil level in bottle- Check app settings.- Follow cleaning instructions from previous page.
Oil Leaking	<ul style="list-style-type: none">- Check if bottle is screwed in tightly.- Check if bottle is overfilled.