## TOWER DIFFUSER



#### LOVE AT FIRST SCENT

#### INTRODUCTION

The Scentify Tower Diffuser is a scent machine that is designed with smart technology that transforms your favorite oil into a gentle fragrance mist. This device covers up to 1000 square feet of area and creates a scented environment. Using the Scentify app via Bluetooth, you are able to customize the Tower settings. This device will impress your visitors with the pleasant aroma of your home and office - it is truly LOVE AT FIRST SCENT

#### PACKAGE INCLUDES

- •1 x Scentify Tower Diffuser
- •1 x 100ml Bottle
- •1x5FootPowerAdapter
- 1x Replacement Straw

#### **TECHNICAL SPECIFICATIONS**

Brand Name	Scentify	
Product Dimensions	112*112*288mm	
Bottle capacity	100ml	
Weight	1.4kg	
Coverage	1000 Sq	
Power	5W	
Connectivity	Bluetooth	

#### SETTING UP THE DEVICE

(3)

diffuser.)



Push down the top cover to

release diffuser nozzle.



Take out the diffuser

the plastic sticker

NOTE: You must remove

surrounding the diffuser

# e

Fill your bottle with aroma

oil and screw in the bottle

(Do not pour oil inside the

to the diffuser nozzle.



(4)

Put the diffuser nozzle with bottle back into the diffuser.



0

(2)

nozzle.

nozzle.

(5) Line up the grooves.

#### (6) Push down and make sure the diffuser nozzle is flush with the diffuser.

(1/8" beneath the diffuser frame)

Press the button to turn ON

#### **OPERATIONS**



(1)

POWER ON/OFF

and OFF the device.

Connect the device with the power cord, the tower will make a beep sound.

NOTE: Screen light will shut off after 60 seconds. Press + or – to wake.



#### SET INTENSITY SETTING

The machine has 9 intensity levels, press the ⊕ button to increase the intensity, press the 🕤 button to decrease the intensity. See chart for details

•-•••

#### POWER INDICATOR

Sign indicates the direction of the power supply.

#### S CONNECTING TO APP – BLUETOOTH

Open the "Google Play" store or "App Store" on your smartphone, search for the **Scentify** app and download.

scentify		
1 Bluetooth version	$\supset$	
WIFI version	$\supset$	
20/30/46/56	$\supset$	



On the Device Control page;

4. You can change your device name and label information of your scent diffuser.

**NOTE:** Press the "Save" button at the top right corner of the screen after each change.

5. Press the schedule you would like to edit.

NOTE: You can set up to 5 different schedules by pressing the + button. To delete a schedule, swipe left. Press the toggle button to turn on/off any schedule.

$\leftarrow$	w	orking p	eriod se	tting 10	Save
Star	t workin	g time	Sto	p working	g time
6	59		10	59	6
7	00	AM	11	00	PM
8	01	PM	12	01	
Repea	at C	Mon F	Tue ri	Wed Sat	7 Sun
√ G	rade		8		4 +
0	ustom				(9)
	Spray Ti	me	5	Pause Tim	•
				23	
	5 S	econds		4 Min	utes
	6			5	

On the "Working period setting" page;

2. Select your device.

password 8888 and press

3. Enter the default

bluetooth)

Login.

**6.** Set the hours of the day you want your diffuser to run by scrolling the "Start working time" and "Stop working time".

7. Select the days of the week you want your diffuser to run (all days are pre-selected).

8. Press + or - to increase or decrease the preset intensity grades (1-9). See chart for details. 9. Check (√) the Custom box to create a custom intensity and scroll the "Spray Time" and "Pause Time".

**10.** Click the "Save" button to update the settings.

Cevice control		
Set	About	
PCB version: V4.02		
Equipment version:V5.1		
App version:V1.0.2		
Change the	a password	
	-	
	(11)	

**11.** You can change the default password by pressing on the "About" tab, in the "Device control" page.

#### RESET BLUETOOTH APP PASSWORD

Press and hold the power button on the diffuser for 3 seconds to reset the password to 8888.

#### RESET TO FACTORY SETTINGS

Press and hold the + and - on the diffuser until you hear a beep.

### INTENSITY AND OIL CONSUMPTION

Grade	Spraying Time	Pause Time	Consume(ml/h)
G1	30 seconds	270 seconds	0.07
G2	60s	240s	0.13
G3	90s	210s	0.20
G4	120s	180s	0.27
G5	150s	150s	0.33
G6	180s	120s	0.40
G7	210s	90s	0.47
G8	240s	60s	0.53
G9	270s	30s	0.60

#### WARNINGS

Always keep the Tower upright. Tilted or angled will cause oil to overflow and damage the diffuser.

(!)

#### EQUIPMENT CLEANING

**1.** Fill the bottle with water-vinegar or rubbing alcohol.

**2.** Let the diffuser run for about 3-5 minutes.

3. Drain the diffuser bottle completely.

4. Using a cotton swab dipped in vinegar, clean the tight spots and corners of the diffuser to make sure that no spots are left dirty.

**5.** Use a dry cloth or cotton swabs to wipe the diffuser and dry it thoroughly.

#### **MAINTENANCE & STORAGE**

• Always turn off or unplug the diffuser when not in use. • Do not move the diffuser while in use.

• Remove the power cord before cleaning.

• Store the diffuser in a dry and clean place.

Problem	Solution
No Diffusion	- Check if the power is ON or OFF.
	- Check oil level in bottle
	- Check app settings or switch to button settings.
	- Follow cleaning instructions above.
Oil Leaking	- Check if bottle is screwed in tightly.
	- Replace the supplied straw that came with the machine.
Bubbling Sound	- There may be too much oil in the bottle.
No Display on Screen	- Make sure the power is ON.
	- Screen light shuts off after 60 seconds. Press + or – to wake.

