



Ceramic Cooktop Touch Control 60cm

Model: CCT6010




- 60cm ceramic glass with quartz grey graphics
- Bevelled shaped edges 22mm x 5mm
- Four German Hi Light elements with rapid boost start up
- Two extendable cooking zones making 6 cooking zone options
- Slider touch control with direct access to nine heating levels with a lighted display
- Automatic cooking
- Four timers
- Minute minder
- Stop and go function
- Keep warm 70°C function
- Recall function
- Child safety lock
- Auto-Stop in case of accidental start, long absence, overflow, over temperature
- Residual heat indicators
- Easy Access Servicing due to service access from below




Easy Access Servicing




Arsenic Free Glass



Extendable Zones



Keep Warm Function



Pause/Resume




Spill Protection



Cooking Elements



Residual Heat Indicator



Automatic Cooking



Boost Startup



Child Safety Lock



Glass Surface Mounted



Glass Flush Mounted



QUALITY ASSURED

To obtain full installation instructions for this appliance go to kleenmaid.com.au and click on User Care Manuals, top right.

Fineline :0015230

J12007_01

Level 2, 204 Botany Road, Alexandria NSW, 2015
P: 02 9310 1207 • E: support@kleenmaid.com.au
www.kleenmaid.com.au

KLEENMAID
The best you can own