

— EVERY JOURNEY TELLS A STORY.

LOGISTICS MASTER™



Logistics Master™ is the **premiere quality control tool** for shipping live and frozen food products.

At the touch of button, record the entire journey and **gain key insight** into the two leading causes of food mortality and lost revenue - temperature and motion.

Logistics Master™ delivers the **quantifiable quality assurance** you need to **secure customer confidence and loyalty**.

Built for the long haul

Featuring a waterproof design, records data of the entire journey*, regardless of environment or shipping disruptions.

Data led quality assurance

Leverage tracking information with Logistics Master™ data. Gain customer loyalty with a data-led shipping quality and transparency.

*up to 7 days

Triple sensor data collection

Measure **Internal temperature**, **External temperature** and **Vibration**. Pinpoint **when**, **where**, and **why** product damage occurred.

Stress-free activation

Start recording at the touch of a button.




Approx. actual size

Logistics Master™ delivers the quantifiable quality assurance you need to secure **customer confidence** and **loyalty**.


Logistics Master™ USB specifications

Model Number	MT-A-LOGM-01
Device Size	80x25x5 mm / 3.15x0.98x0.20 inch (LxWxH)
Device Size with Protective Sleeve	110x40x5.5 mm / 4.33x1.57x0.22 inch (LxWxH)
Cable Length	50 cm
Weight	25 g / 0.06 lb
Battery	Dual Non-removable 2032 Lithium Battery
Recording (Power On)	Up to 7 days
Standby Time (Power Off)	Up to 1 year
Operation Temperature	-20~50 °C
IP Rating	IP68
Persistent Recording	Yes
Data Display Interval	120 seconds (Highest recorded value)
Data Entries	Up to 20,000 entries
Acceleration Sensor	Digital 3-axis Accelerometer
Measurement Range	±8 g-force (±0.05 g-force)
Sensitivity Range	0.004 g-force
Temperature Sensor	Dual Digital Temperature Sensors
Measurement Range (Internal)	-20~85 °C (±0.5 °C)
Measurement Range (Ambient)	-20~85 °C (±0.5 °C)
Sensitivity Range	0.1 °C


How to use:




Peel the adhesive backing from the device.



Stick the device to the outside of the product crate.



Press the button to activate the device (cannot be deactivated).



% **Low investment, high return**

Collect days worth of data with almost ZERO impact to your shipping weight.

🔌 **Plug & play**

Access your data easily through USB connection.



NB Office: Annex 1 - 40 Charlotte Street, Saint John, New Brunswick, Canada E2L 4V1
 NS Office: Unit 100 - 1505 Barrington Street, Halifax, Nova Scotia, Canada B3J 3K5
info@marinethinking.com
sps.marinethinking.com



Buy Now
mrobotics.ca