



**Circuit breaker
(Prior to removing it
from the metal base)**



**With a pair of pliers, grip
one of the contacts of
the circuit breaker and
pull on it to remove it
from its base**



**Once removed, you can
install this into the base
of the circuit breaker
within your battery box**