

JMS86 Series Instructions



CHARGING

The *JMS86* has a built-in charger. To charge, slide out the charger and plug into a standard wall outlet. It takes approximately 6-8 hours to fully charge. Every 2 months or when the spark or light is noticeably weaker, the unit should be charged.

HOW TO USE

Make sure the unit is fully charged and the disable pin is inserted before first use. To use the light, simply slide the safety switch to the first position. For the stun gun, slide the safety switch to the second position and press the shock button. Don't test fire for more than 3 seconds.

WARRANTY

Cutting Edge Products, Inc. extends a Lifetime Warranty to the *JMS86* for the product against defects in materials or workmanship, with the following exceptions:



- The warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, moisture, the affixing of any attachment not provided with the product, loss of parts, or recharging the unit in any manner not in accordance with the included instructions.
- The warranty will be voided if the unit has been opened or tampered with in any way (unless by an Authorized Dealer) or if any unauthorized replacement parts have been used.
- The Lifetime Warranty covers the stun gun only. The holster and the lanyard attached to the disable pin are excluded.

TO OBTAIN SERVICE

Contact the Authorized Dealer from whom you purchased this unit for a Return Merchandise Authorization. The return unit must be sent postage prepaid and proof of purchase is required. Damage or loss occurring during shipment is not covered by this warranty.

JMS86 Series Instructions Rev 4/10/2018