


# Tic Tac Toe / Dry Erase Board

**STEP 1:** Decide on your chosen location for the Tic Tac Toe Board. It can be installed under the play deck at the same height as the ladder between Post A6 and A7 or between Post A7 and A8.


**STEP 2:** In the desired location, insert the Tic Tac Toe Board between the posts and align with the bolt holes. Use four (4) 3/4" bolts, washers, lock washers, and nuts to attach to the posts. Tighten using wrenches.

**NOTE:** It is easiest to install the board during original setup. If adding it on later, you will need to loosen bolts along one side of the entire post in order to fit the board between the posts without causing damage to the coating.



SHOWN IN CONFIGURATION 1

**STEP 3:** Add magnets to the back of the tic tac toe grid. Place the tic tac toe magnets to the board and start playing! Dry erase markers can also be used on the board and easily wiped off.



**PLEASE NOTE:** The tic tac toe board cannot be used to replace an upper railing as it is not tall enough to meet safety standards.