STREAMLINE®

Products for the Pure Water Cleaning Industry

INSTRUCTION MANUAL

PRODUCT

STREAMBOX™ 25 Litre Trolley System.

PART NUMBER

- TR25.SL-BC
- TR25.SL-BC-SFC5
- TR25.SLF-BC
- TR25.SLF-BC-SFC5

WARRANTY

Covered for one year from recorded date of purchase. (See back page for further details).



Packed By	Checked By
<u> </u>	•

Date ____/___

RESIN FILTER OPTION

If the trolley is fitted with this option, connect the hose from the outlet of the streambox to the inlet of the blue resin filter. (LH connction) Connect the hose from the outlet of the resin filter (RH connection) to the hose reel or pole.

If the trolley has no resin filter, connect the hose from the outlet of the Streambox to the hosereel or pole. Fill the water container. The unit is now carrying in excess of 40kg of weight. Extreme care should be taken when transporting or wheeling the unit around.





Insert the check valve riser into the full container and screw the lid on.

The check valve prevents water loss whilst changing containers.

FILTER SERVICING (IF FITTED WITH THIS OPTION)

Regular meter readings should be taken using the enclosed TDS meter to ensure that the system is producing pure water. When the water TDS no longer registers 000, remove the blue resin filter from the trolley and unscrew to top black head. Draw the riser tube from the resin contents. Dispose of the spent resin in a responsible manner. It is not harmful to the environment. Once the empty vessel has been flushed out with water, refill the filter housing with new resin leaving an air gap of approximately 2". Carefully push the riser into the resin. Shake the filter housing in order to allow the riser to 'bottom'. Clean the sealing edge of the housing before securing the top.

THE PUMP PRE-FILTER

The pump pre-filter ensures that the ingoing tap water is free of any debris or sand particles. Any accumulation of debris can be removed by unscrewing the filter and flushing it out. Reconnect in the same manner. No debris should be allowed in to the pump as this can cause the pump to fail.



The pump also has a built in pressure switch. When switched on it will pump until it has reached the maximum pressure setting before cutting out. This is a safety feature to protect the pump. Never leave the pump stored under pressure as this may lead to pump failure. The pump runs off a rechargeable battery. You should be able to operate for up to 8 hours on a single charge.

CHARGING

To charge the battery, use charger supplied. Connect XLR plug into charging socket on the trolley and connect 3 pin plug to mains. Further details relating to charger can be found in the charger instructions, included with the charger.



STREAMLINE® WARRANTY

The warranty on Machines and Equipment is for 1 year from RECORDED DATE OF PURCHASE.

THIS WARRANTY EXCLUDES NORMAL MAINTENANCE ITEMS, including but not limited to HOSES, FILTERS, O-RINGS, DIAPHRAGMS, VALVES, GASKETS, CARBON BRUSHES and damage to motors and other components as a result of failure to replace normal maintenance items. THIS LIST IS NOT EXHAUSTIVE.

If VARITECH receives notice of such defects during the warranty period, **STREAMLINE**® will either, at its opinion, repair or replace components which prove to be defective.

Replacement parts will only be supplied under warranty, upon the inspection and approval of the defective parts by **STREAMLINE**®.

Should it be necessary to supply replacement parts before the opportunity to inspect, these will be charged at current prices and credit will only be issued upon subsequent inspection and warranty approval by **STREAMLINE**®.

The customer is responsible for the cost of return of the defective part. If warranty is approved, **STREAMLINE**® will pay for the cost of the repaired or replacement part.

REPLACEMENT PARTS SUPPLIED UNDER WARRANTY WILL BE GUARANTEED FOR THE REMAINDER OF THE ORIGINAL PARTS WARRANTY AND NOT FROM THE INSTALLATION DATE.

This warranty excludes the following conditions and circumstances which are at the discretion of **STREAMLINE**®:-

WEAR AND TEAR, MISUSE, ABUSE, IMPROPER MAINTENANCE, FROST DAMAGE, THE USE OF CHEMICALS OTHER THAN THOSE SUPPLIED OR APPROVED BY **STREAMLINE**®, IMPROPER INSTALLATION OR REPAIR, UNAUTHORISED MODIFICATION, INCIDENTAL OR CONSEQUENTIAL COSTS, LOSS OR DAMAGE, SERVICE, LABOUR OR THIRD PARTY CHARGES, THE COST OF RETURNING DEFECTIVE PARTS TO **STREAMLINE**®.

This warranty constitutes the exclusive remedy of any purchaser of a **STREAMLINE**® unit and is in lieu of all other warranties, express or implied, including without limitation any implied warranty of merchantability or fitness for use, to the fullest extent permitted by law. In no event shall any implied warranty of merchantability or fitness for use exceed the term of the applicable warranty stated above and **STREAMLINE**® shall have no other obligation or liability.

These rights cannot be transferred to a third party.

WHY **STREAMLINE**[®]?

FLEXIBILITY

- **STREAMLINE**® systems can be built according to customers' exact requirements.
- For non-standard systems, the user's needs or specifications are listened to and turned into reality.

QUALITY

- Whilst price is important, quality is remembered long after price is forgotten.
- We insist on sourcing brand name products from around the world, only of a reputable quality, and bring them together under the STREAMLINE® name.
- All **STREAMLINE**® products carry a full one year's warranty, according to the manufacturers' standard terms and conditions of sale.

SERVICE

- We have an in-house technical helpline able to answer most of your questions relating to the capabilities and functionalities of all **STREAMLINE**® products.
- If we get it wrong, we will put it right. If you are sent a wrong item, we will immediately attend to sending you the correct item and arrange a collection of the wrong item without any quibbles.
- **STREAMLINE**® is backed by a comprehensive range with massive stocks providing you with a 'one stop shop' for all your requirements.

YOU ARE IN SAFE HANDS







