


new balance


SPORT EYEWEAR COLLECTION - LENS INSERTION INSTRUCTIONS




Step 1:
Unscrew these two screws.



Step 2:
Take out Part A and unscrew these two screws on Part B.



Step 3:
Take out Part B and unscrew the screw on Part C.



Step 4:
insert the lens. Reassemble starting with Part C.

US Patent No. US 11,061,250 B2

UNISEX M/L

FOR ADDITIONAL INFORMATION CONTACT;
EYEWEAR DESIGNS LTD.

www.eyeweardesigns.com • (800) 645-6596

CARE FOR YOUR FRAMES

- Use lukewarm water with mild soap onto your fingertips gently rub the lenses, frame, and nose pads to remove dirt, oils, and smudges
- The lenses should be replaced when scratches become troublesome, or if cracks appear on the edges.
- Should the eye protector be severely impacted, short of failure, then the degree of protection provided will be reduced and the eye protector must be replaced. Failure to do so may result in permanent injuries to the eye.
- Should the lens pops out due to impact during play, the wearer should stop playing and have the protector replaced
- Should the eye protector be stored at cold temperatures it should be allowed to return to room temperature before use
- The product cannot protect against all eye and facial injuries, or brain injuries, the user might suffer while participating in racket sports
- Lens mounting instructions listed above for RX lenses




new balance

SPORT RX