


SURGE





HEAVY DUTY LED FLASHLIGHT

OPERATING INSTRUCTIONS



BATTERY REPLACEMENT: Install batteries by removing tail cap. Place six AA batteries in battery tray as shown. Insert battery tray with positive (+) end toward head of flashlight. Replace tail cap. Use alkaline batteries for maximum brightness and life.

Note: Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (NiCd, LiFeO₄) batteries.

PUSH BUTTON SWITCH: Press button switch in tail cap of flashlight to cycle through lighting modes: High, Low, Strobe.

1-YEAR LIMITED WARRANTY: This product is guaranteed to be free of defects in material and workmanship for one year from date of purchase to the original owner. If this product is defective, call our Customer Service at 855-735-9922 for repair or replacement parts or return the product to store from which it was purchased. Guarantee does not include normal wear and tear, batteries or damage caused by batteries (i.e. leakage).

Fair Game Group LLC Carrollton, TX 75006 www.surge-lighting.com

A WARNING

To prevent damage to eyesight, never look into light when light is on. Do not shine light into the face of someone else.



Batteries must be recycled or disposed of properly

Model HHL3060AS