
Cuisinart

4 Burner Dual Fuel Gas Grill

ASSEMBLY INSTRUCTIONS

Model GAS1456ASO



ASSEMBLY INSTRUCTIONS:

A READ ALL SAFETY WARNINGS & ASSEMBLY INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR OPERATING YOUR GRILL.

WE RECOMMEND TWO PEOPLE WORK TOGETHER WHEN ASSEMBLING THIS UNIT.

The following tools are required to assemble this Cuisinart 4 Burner Gas Grill:

• Phillips Screwdriver

PARTS LIST:


1	1	Front Right	Leg

- (2) 1 Front Panel
- (3) 1 Front Left Leg
- (4) 1 Right Side Panel
- (5) 1 Left Side Panel
- (6) 1 Cart Brace
- (7) 1 Cart Base
- 8 1 Left Rear Leg
- (9) 1 Back Panel
- 10 1 Right Rear Leg
- (11) 1 Side Burner Grate
- (12) 4 Heat Tents
- 13 1 Side Burner Knob
- 1 Right Side Control Panel

- 15 1 Grease Cup
- (16) 1 Warming Rack
- (17) 1 Heat Shield
- (18) 1 Right Side Table
- (19) 1 Left Side Table
- (20) 1 Grill Body
- (21) 1 Left Side Control Panel
- (22) 4 Casters
- 23 3 Cooking Grates
- 24) 1 Grease Tray
- 25 1 Bar


Note: Most hardware is pre-attached to the grill. You may need to loosen some screws partially while others may need to be removed in order to assemble parts. The screws that you remove will be re-used so don't misplace this hardware.

Extra screws are included in a small bag with the owners manual.




Step 1a

- Loosen screw on each BRACKET
- Rotate all BRACKETS upward and lock into slot
- Tighten screws



Step 1b

- Loosen 6 screws
 3-4 turns on
 FRONT LEGS
 and
- Do not remove screws
- Attach FRONT PANEL 2 using keyholes
- Tighten 6 screws




NOTE: Before tightening keyhole screws, make sure panels are aligned.

RIGHT SIDE PANEL 4 Francisius


Step 2


- Loosen 3 screws
- Attach RIGHT
 SIDE PANEL 4
- Tighten 3 screws on RIGHT SIDE PANEL 4




- Loosen 2 screws
- Attach LEFT
 SIDE PANEL 5
- Tighten 2 screws on LEFT SIDE PANEL 5


- Remove 6 screws
- Attach CART BRACE (Stored in Grease Tray)
- Tighten two screws on CART BRACE 6









- Loosen 6 screws
 on REAR LEGS
 and 10
- Attach BACK PANEL 9
- Tighten 4 screws
- Remove 6 screws




- Attach CART
 BASE to rear
 legs
- Tighten 4 screws (Removed from Step 6)


- Attach LEFT
 SIDE PANEL 5
 and CART
 BRACE 6
- Tighten 4 screws







Set cart upright on CASTERS




Step 11a

Loosen 2 bottom screws

Step 11b

- Install BAR 25
- Tighten 2 screws




Step 12


LEFT SIDE


- Loosen screw
- Remove 2 screws

RIGHT SIDE


- Loosen screw
- Remove 2 screws







- Set GRILL
 BODY 20 on cart
- Make sure screw drops into rear cart brackets
- Align GRILL BODY 20 to front of cart




Step 14


LEFT SIDE


Tighten 2 screws


RIGHT SIDE

Tighten 2 screws










LEFT SIDE TABLE

Step 17


- Loosen 4 screws
- Attach LEFT SIDE TABLE using keyholes
- Do not tighten screws at this point in time




 Install screw and tighten (screw was removed in Step 12)





- Install screw and washer (screw and washer were removed in Step 15). Do not tighten screw at this time
- Make sure panels are aligned
- Tighten 5 screws from Steps 17 through 19



- Loosen 4 screws
- Attach RIGHT SIDE TABLE 18 using keyholes. Do not tighten 4 screws at this time








4


Step 21

 Install screw and tighten (screw was removed in Step 12)




- Install screw and washer (screw and washer were removed in Step 15). Do not tighten screw at this time
- Make sure panels are aligned and tighten 5 screws from Steps 20 through 22

 Install screw (removed in Step 15)




Step 24a


- Remove WING NUT and remove burner. Install SIDE BURNER VALVE in control panel
- Slide valve downward and tighten 2 screws to lock into place (see diagram Step 24b)
- Install burner and make sure BURNER VENTURI fits over VALVE NOZZLE
- Tighten WING NUT



Step 24b




Install SIDE
BURNER
KNOB 13



Step 25a


Attach WIRE CLIP to side burner


Step 25b




Step 26

 Attach IGNITOR WIRE to ELECTRODE






Install SIDE BURNER GRATE 11




- Loosen 2 screws
- Attach HEAT
 SHIELD and
 tighten screws



Step 30

Install HEAT
TENTS 12,
COOKING
GRATES 23 and
WARMING
RACK 16



Model GAS1456ASO Assembled

