



# LED MULTI-COLOR STRING LIGHTS OWNER'S MANUAL

## ASSEMBLY AND OPERATING INSTRUCTIONS

**SAVE THIS MANUAL FOR FUTURE REFERENCE**

## Model OLT2047AS

### **⚠ WARNING**

When using outdoors basic safety precautions should always be followed to reduce the risk of fire, electrical shock and personal injury. Install lights by following these instructions and current electrical codes such as the National Electric Code (NEC).

When use outdoors in wet locations. Ground fault circuit interrupter protection is to be provided with the circuits or outlets. The receptacle cover should always be in place to prevent the entry of water (unless a plug is inserted).




## General Warnings:

- ⚠ **CAUTION:** Risk of Electrical Shock. Avoid making connections or disconnections when the equipment is wet. Do not submerge. Keep receptacles and bulbs at least 16 feet from pools and spas. Keep receptacles dry.
- ⚠ **WARNING:** RISK OF ELECTRICAL SHOCK! Disconnect power at the source prior to wiring, changing bulbs or servicing the string lights.
- ⚠ **CAUTION:** To reduce the risk of fire, shock or injury to persons:
  1. String Lights are intended for installation indoor or outdoor only.
  2. String lights must be supported by steel guide cables or other suitable supporting hardware such as S-hooks, screws or Zip-ties (not included) whenever span distances exceed twenty-four feet (7.5 meters) see installation methods on page 2.
  3. String lights must be installed with the receptacles and bulbs are facing downward ONLY.



4. Keep combustible material clear around bulbs. Do not allow bulbs or receptacles to come into contact with fabrics such as shades, curtains or blinds or other combustible materials. Bulbs should hang freely with a minimum clearance of 3 in. from all objects.



5. Do not cluster the bulbs together.



6. String lights are not intended for installation in ceilings, cabinets or other enclosed spaces.



7. Avoid damage to insulation during installation. Do not pierce or otherwise damage the connecting wire or receptacles outer covering, jacket or sheath.
8. Periodically inspect the wire and receptacles for degradation due to weather, UV light, animals or other damage. If damaged, replace worn string lights immediately.
9. Only connect a maximum of two string lights in tandem. Use only 12 volt LED bulbs designed for this string light set. Use of other types of bulbs can damage the string lights and cause them to stop working.




**⚠️ READ ALL SAFETY WARNINGS & ASSEMBLY INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR OPERATING YOUR STRING LIGHTS.**

FOR MISSING PARTS, PLEASE CALL CUSTOMER SERVICE AT 855-735-9922.  
 Inspect contents of the box to ensure all parts are included and undamaged.

**Component Contents:**

- |                                  |                          |              |
|----------------------------------|--------------------------|--------------|
| 1 String Lights Harness (24 ft.) | 2 AAA Alkaline Batteries | 12 LED Bulbs |
| 1 Remote                         | 1 Extension Cord (5 ft)  |              |



**Assembly Instructions:**

We recommend using a guide wire with S-hooks or zip ties (not included) to hang your string lights.

- Method 1.** Anchor your guide wire securely at one end and thread the string lights through the guide wire using the eyelets at each bulb junction.
- Method 2.** Anchor your guide wire securely at one end and attach string lights to the guide wire using the S-hooks at each bulb junction.
- Method 3.** Anchor your guide wire securely at one end and attach string lights to the guide wire using the Zip-ties at each bulb junction.



### Inserting Bulbs:

Screw bulbs into receptacles by holding socket firmly in one hand and twisting bulb clockwise. Bulbs may be tight in sockets, this is normal to prevent moisture from getting into the receptacle.



### Attaching Controller Box:

Connect remote control box to wiring harness by aligning the two prongs and making sure the flat section of the male connector is below the opening of the two prongs in the remote control box connector.




Insert fully and tighten the locking nut by twisting clockwise for a water tight connection.



## Remote Operating Instructions:

- Brightness/  
Frequency** Press the Brightness/Frequency buttons to change individual color brightness. Total 12 colors. When using preset modes, these buttons change the frequency some effects.
- Strobe:** Most bulbs will be one color. Another color will appear at random along the string lights. Press the button to change color. The colors are red with light blue / green with purple / blue with yellow / yellow with blue / light blue with red / purple with green in order.
- Fade:** The string lights will change colors continuously. The colors are red, orange, yellow, green, light blue, blue, purple, pink in order.
- Twinkle:** The string lights will quickly flash 3 times then change into another color. These colors are white, purple, light blue, yellow, blue, green, red in order.
- Breathe:** The string lights will slowly flash 3 times then change into another color. These colors are red, green, blue, yellow, light blue, purple, white in order.
- Chaser:** Bulbs cycle on and off to give the illusion of lights moving along the string. Press the button to change to other color combinations. Six Total programs. Three programs are single color. These colors are red, green and blue in order. The other three programs are multi-color. These colors are light blue and red / purple and green / multi-color (red, yellow, green, purple, white and light blue).
- Random:** All bulbs will change colors randomly.
- RGB Flash:** All bulbs flash the same color. You can press the button to change the color (red, green, blue, yellow, purple, light blue and white, then RBG flash).
- Reminder:** When you are playing single color light you can press the Brightness/Frequency buttons to adjust the brightness up or down. When you are playing a program function like Strobe or Fade, the Brightness/Frequency buttons will adjust the frequency of the flashes.

## Remote Control:



Remote uses 2 AAA alkaline batteries.

**⚠ WARNING:** Keep old and new batteries out of the reach of children and pets and seek immediate medical attention if a battery is ingested. Swallowing a battery can be harmful. Contents of an open battery can cause chemical burns of the mouth, esophagus and gastrointestinal tract.

 Batteries must be recycled or disposed of properly.

**⚠ CAUTION:** Batteries may explode or leak if recharged, inserted improperly, disposed of in fire or mixed with different battery types.



## 1-YEAR LIMITED WARRANTY

For 1-year from date of purchase, Fair Game Group warrants the LED Multi-color String Lights against defects due to workmanship or materials to the original purchaser.

Fair Game Group's obligations under this warranty are limited to the following guidelines:

- This warranty does not cover lights that have been altered/modified or damaged due to: normal wear, abuse, improper maintenance and/or improper use.
- This warranty does not cover surface scratches or heat damage to the finish, which is considered normal wear.
- Fair Game Group may elect to repair or replace damaged units covered by the terms of this warranty.
- This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers.

Fair Game Group requires reasonable proof of purchase. Therefore, we strongly recommend that you retain your sales receipt or invoice. To obtain replacement parts for your LED Multi-color String Lights under the terms of this warranty, please call Customer Service Department at 855-735-9922 for a **Return Authorization Number** and further instructions. **A receipt or proof of purchase will be required.** Fair Game Group will not be responsible for any lights forwarded to us without prior authorization.

EXCEPT AS ABOVE STATED, FAIR GAME GROUP MAKES NO OTHER EXPRESS WARRANTY.

THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO 1-YEAR FROM THE DATE OF PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

ANY LIABILITY FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE FAILURE OF THE LED MULTI-COLOR STRING LIGHTS TO COMPLY WITH THIS WARRANTY OR ANY IMPLIED WARRANTY IS EXCLUDED. CUSTOMER ACKNOWLEDGES THAT THE PURCHASE PRICE CHARGED IS BASED UPON THE LIMITATIONS CONTAINED IN THE WARRANTY SET OUT ABOVE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

OM2047AS  
1222, 0923

©2022 Fair Game Group LLC.  
Carrollton, Texas 75006 U.S.A.  
[www.lux-lanscape.com](http://www.lux-lanscape.com)

Owner's Manual for Model  
OLT2047AS