

# CARE AND USE OF TRAYS



All Photo Phactory pieces of trays are everyday art that's designed to be used. To keep them beautiful for many years, follow these guidelines for their care.

Each tray is made with Solid MDF wood finished with lamination and varnish.




Please use it to serve dry stuff / tea / coffee.  
Use damp cloth to clean the surface.  
It's water resistant not water proof !

Never put the tray in the dishwasher, or leave in standing water.



Never place your your tray in the microwave

Do not use abrasive scouring pads or other rough materials on this product.



Displaying in sunny windows for extended periods is not recommended.

All the very best and thanks for all the support !