

How to Change Batteries in The Purr-Low



You need The Purr-Low™, a screwdriver and three new triple A batteries.



Locate the zip at one end and pull the fur away gently from the zip.



Open up The Purr-Low™ and locate the sound box inside a white pouch. Pull it up.



Inside the pouch, pull out the sound box.



Grab the screwdriver and open up the battery compartment lid.



Replace with new batteries then screw it back up.



Once tightened, put the soundbox back into the white pouch.



Return the pouch back into The Purr-Low™ lycra bag and zip it up.



Then you're done!

