

Applicable Models: Aria & Aria LX

In ARIA and ARIA LX You can access a settings menu using the buttons on the throttle. These are called “P” settings (P for program)

There are 5 hidden modes in P settings: P0, P1, P2, P3, P4

- **P0** is to change the speed between mph and km/h
- **P1** is to turn on and off the cruise control function. (Our product comes with the default cruise control function on).
- **P2** is to change from “zero start” to “kick to start”. By default, you have to push the scooter with your foot to achieve a minimum rolling speed and for the throttle to engage.
- **P3** is to change the tire diameter (no need to change but should be in 10 for Aria LX).
- **P4** is to change the top speed of the scooter.

To access the P Settings:

There are two buttons in the throttle:

1. The Power button (bottom one)
2. Function button (upper one with 3 white bars)

P0 Menu – SPEED UNITS**Change from km/h to mph**

1. Press both buttons at the same time to enter the P menu.
2. Scroll to P0 by pressing the function button.
3. Once in P0 press the power button to enter the P0 setting menu.
4. Scroll through the options of P0 by pressing the function button.
5. Scroll and select 0 which means km/h or 1 which means mph
6. Press the power button again to exit the P menu.
7. Press and hold the power button to turn off the scooter.
8. The speed units setting should now be changed.

P1 menu – CRUISE CONTROL**Activate / deactivate cruise control feature**

9. Press both buttons at the same time to enter the P menu.
10. Scroll to P1 by pressing the function button.
11. Once in P1 press the power button to enter the P1 setting menu.
12. Scroll through the options of P1 by pressing the function button.
13. Scroll and select 0 which means cruise control off or 1 which means cruise control on.
14. Press the power button again to exit the P menu.
15. Press and hold the power button to turn off the scooter.
16. The setting should now be changed and the Cruise control function is disabled.

P2 Menu – KICK PUSH TO START

Change from “zero start” to “push to start”

1. Press both buttons at the same time to enter the P menu.
2. Scroll to P2 by pressing the function button.
3. Once in P2 press the power button to enter the P2 setting menu.
4. Scroll through the options of P2 by pressing the function button.
5. Scroll and select 0 to turn off kick to start or 1 to turn it on..
6. Press the power button again to exit the P menu.
7. Press and hold the power button to turn off the scooter.
8. The setting should now be changed.

P3 Menu - WHEEL SIZE CHANGE

Change wheel size

This option is created to program the speed sensor for both scooter models (Aria and Aria LX) and/or different wheel sizes from factory.

It should be at 10 in Aria LX and 85 in Aria. **DO NOT MODIFY THIS SETTING.**

P4 Menu – SPEED LIMITER

The Aria and Aria LX are equipped with an electronic speed limiter that can be adjusted.

If should be at 10 in Aria LX and 85 in Aria.

1. Press both buttons at the same time to enter the P menu.
2. Scroll to P4 by pressing the function button.
3. Once in P4 press the power button to enter the P4 setting menu.
4. Scroll through the options of P4 by pressing the function button.
5. Scroll and select one of the following :
 - a. 20 = 20 km/h (13 mph)
 - b. 25 = 25 km/h (15 mph)
 - c. FF = Max Speed (unrestricted)
 - i. Aria LX Max Speed = 18-20 mph
 - ii. Aria Max Speed= 16
6. Press the power button again to exit the P menu.
7. Press and hold the power button to turn off the scooter.
8. The setting should now be changed.

Please reach our tech support team for further questions at **support@ettrone.com**