



WIRELESS HEADPHONES

LE20BTOHBK, LE20BTOHBL, LE20BTOHRD, LE20BTOHWH, LE20BTOHTL,
LEWBTOHBK, LEWBTOHBL, LEWBTOHWH, LEWBTOHPK

Specifications:

Driver Size: 40mm
Impedance: 32 Ohm \pm 15%
Sensitivity: 99dB \pm 3dB at 1kHz
Frequency Response: 20Hz - 20kHz
Wireless Range: 10m
Play Time: 40 Hours
Standby Time: 65 Hours
Battery Size: 400mAh
Charge Time: 2 Hours

Included:

1 x Wireless Headphone
1 x USB to USB-C charging cable
1 x 3.5mm Audio cable

Battery Charge:

This wireless headphone is powered by a rechargeable Li-ion battery.
When the battery is low the headphones will emit a sound to remind you to recharge it.

1. Insert USB charging cable into a 5V 1A USB port for charging.
2. Connect the USB charging cable with the USB-C port on the headphone.
3. The LED indicator turns red to show battery is charging.
4. The LED indicator turns off when battery is fully charged.
5. It takes about 2 hours to fully charge the headphone.

How to use this Headphone:

A. Power ON/OFF

| Function | Operation | LED indicator |
|-----------|---|--|
| Power ON | Press and hold the power button (1) for 3 seconds | LED indicator turns blue and the headphone issues a voice prompt 'Power On' |
| Power OFF | Press and hold the power button (1) for 3 seconds | LED indicator flashes red, then goes out and headphone issues a voice prompt 'Power Off' |

B. Pairing the Headphone

1. To enter pairing mode, ensure headphone is OFF, then press and hold the power button (1) for 5 seconds until the LED indicator flashes blue and red, and a voice prompt 'Pairing Mode' can be heard.
2. On your device search for the pairing name: LE WIRE FREE
This applies to all colours.
Once connected the voice prompt 'Connected' can be heard.
(Note: The headphones can be connected directly via the 3.5mm audio cable).

Overview:

1. Power button
2. USB-C charging port
3. LED indicator
4. 3.5mm Audio cable port
5. Built-in microphone
6. Decrease volume/Previous track
7. Play/Pause/Answer call/End call/Reject call
8. Increase volume/Next track

Function

Pause

Operation

Press button (7)

Play

Press button (7)

Next Song

Press and hold button (8)

Previous Song

Press and hold button (6)

Volume Up

Press button (8)

When the volume is adjusted to maximum you will hear an indication tone

Volume Down

Press button (6)

Answer Call

Press button (7)

End Call

Press button (7)

Reject Call


Press and hold button (7) for 2 seconds

Voice Activation

Press and hold button (7) for 3 seconds until activated

Music/Gaming Mode

Press button (7) twice in quick succession



Modes - Gaming/Music

- This headphone is equipped with dual modes - gaming and music.
- To switch between modes, press (7) twice and you will hear a voice prompt signaling which mode you are in.
- Gaming mode - has lower latency than music mode.
- Music mode - has higher focus on sound quality.

Liquid Ears™

PO Box 5658 Brendale QLD Australia 4500

Customer Support 1800 812 261

www.liquidears.com

DESIGNED IN AUSTRALIA

Continuous use at full output may damage hearing.
Liquid Ears is a registered trademark.

