

DUAL ALARM CLOCK RADIO




LEFMCR



USER MANUAL

DESCRIPTION

1. ON/OFF/FM/AM
2. HOUR/TU-
3. MIN/TU+
4. DIMMER/SLEEP/SNOOZE
5. AL 1/VOL-
6. AL 2/VOL+
7. SET/PRE M+
8. LED DISPLAY
9. BATTERY COMPARTMENT
10. SPEAKER
11. POWER CORD
12. ANTENNA



Set Time

1. Press and hold SET button until display starts to flash
2. Press HOUR button to set the correct hour (AM/PM indicator shown on display)
3. Press MIN button to set the correct minutes
4. When complete press SET button to exit

Set Display Brightness

1. Press DIMMER button to change display brightness

Radio Operation

1. Press ON/OFF button to turn radio on
2. Press FM/AM button to select FM or AM band
3. Press PRE M+ button until desired radio station is reached
4. Press VOL + to increase radio volume
5. Press VOL - to decrease radio volume

Memory Presets

1. Press ON/OFF button to turn radio on
2. Press FM/AM button to select FM or AM band
3. Press TU- or TU+ to change radio frequency or;
4. Press and hold TU- or TU+ to scan radio frequency
5. When desired station is found press and hold SET button until display flashes
6. Press TU- or TU+ to allocate memory position from P01 to P10
7. Press SET button to save and exit
8. Repeat process until all radio stations are saved

Sleep Function

1. Press ON/OFF button to turn radio on
2. Press SLEEP/SNOOZE button once to activate 90 minute Sleep Timer. Each press of the SLEEP/SNOOZE button will reduce the count down time by 10 minutes
3. Press SLEEP/SNOOZE button again to set desired count down time in minutes
4. Radio will turn off when countdown timer reaches 0

Set Alarm

1. Press and hold ON/OFF button to enter Time mode
2. Press AL 1 button to enter Alarm mode (display will flash)
3. Press HOUR button to set desired wake hour
4. Press MIN button to set desired wake minutes
5. When complete display will flash for 3 seconds and return to Time mode
6. To set second alarm repeat above steps using AL 2 button

Activate Alarm

1. To wake up to Buzzer press AL 1 button until dot appears next to Buzzer on the display
2. To wake up to Radio press AL 1 button until dot appears next to Radio on the display
3. To turn alarm off press AL 1 until dot disappears from the display
4. Repeat process for Alarm 2 using AL 2

Snooze Alarm

1. Press ON/OFF to stop the alarm
2. Press SLEEP/SNOOZE button to pause alarm for 9 minutes

Clock Memory

When batteries are installed, LEFMCR Dual Alarm Clock Radio can be unplugged from the power outlet and moved to a new location without losing the set time

Specification

Power Supply: 240V a.c. 50Hz

Power Consumption: 5W

Battery Power Reserve: 2 x AAA Batteries
(Not Included)

Frequency Range:

FM: 87.5 ~ 108 MHz

AM: 522 ~ 1620 kHz



Liquid Ears™

PO Box 5658 Brendale QLD Australia 4500
Customer Support 1800 812 261

www.liquidears.com

DESIGNED IN AUSTRALIA

