

# WIRELESS HEADPHONES

LEOEBK, LEOEBL



## Specifications:

Driver Size: 40mm  
 Impedance: 32 Ohm  
 Sensitivity: 103dB ± 3dB  
 Frequency Response: 20Hz – 20kHz  
 Battery Capacity: 400mAh  
 Play Time: 40 Hours  
 Charging Time: 2 Hours  
 Standby Time: 100 Hours  
 Wireless Range: 10m

## Included:

1 x Wireless Headphone  
 1 x USB-A to Micro USB charging cable  
 1 x 3.5mm Audio cable  
 1 x Instruction manual

## Overview:


1. **Volume +**: next track
2. **MF Button**: power on/off, play/pause, answer/end/reject call, voice assistant, mode change
3. **Volume -**: rewind track
4. **3.5mm Audio cable port**
5. **Microphone**
6. **Micro USB charge port**
7. **LED indicator**

## Battery Charge:

This wireless headphone is powered by a rechargeable Li-ion battery.

When the battery is low the headphones will emit a sound to remind you to charge it.

- Insert USB charging cable to a suitable USB port for charging.
- Connect the USB charging cable with the Micro USB port on the headphones.
- The LED indicator turns red to show battery is charging.
- The LED indicator turns off when the battery is fully charged.
- It takes about 2 hours to fully charge the headphone.



## Bluetooth® Pairing

1. To enter pairing mode, ensure headphone is OFF, then press and hold the **MF button** (2) until the **LED indicator** (7) flashes blue and red, and a voice prompt “Pairing Mode” can be heard.
2. On your device search for the pairing name: **LE WIRE FREE** and once selected the LED indicator will turn off and a voice prompt “**Connected**” can be heard.
3. Once paired, the headphone will automatically connect to the same Bluetooth® device.
4. If you want to pair a new device to the headphone, press and hold the **MF button** (2) until the **LED indicator** (7) flashes blue and red, this will take longer than for the first time pairing. Approximately 5 seconds.

## Wired Connection

1. If you wish to use the headphone in a wired mode, simply connect the supplied 3.5mm Audio cable into the port (4) on the headphone and insert the other end into a source device.
2. To use in a wired mode, you are not required to turn the headphone on, simply control the audio via the source device.

## Playing Music via Bluetooth®

1. Press **MF button** (2) to play music. Press again to pause music.
2. Press and hold “**+**” **button** (1) to skip to next track
3. Press and hold “**-**” **button** (3) to rewind track
4. Press “**+**” **button** (1) to increase volume, voice prompt can be heard when maximum volume is achieved
5. Press “**-**” **button** (3) to decrease volume

## Answer / End Calls

1. To answer an incoming call, press **MF button** (2)
2. To end a call, press **MF button** (2)
3. To reject an incoming call, press and hold **MF button** (2) for 2 seconds
4. The **microphone** (5) is located on the headphone

## Voice Assistant

1. In a powered on state and not on a call, press and hold the **MF button** (2) for 2 seconds to activate your connected phone’s voice assistant.
2. Once activated, any music playing will pause and you can then communicate with the assistant.

## Modes – Gaming / Music

1. This headphone is equipped with dual modes – gaming and music
2. To switch between modes double press the **MF button** (2) and you will hear a voice prompt signaling which mode you are now in.
3. Gaming mode – has a lower latency than music mode
4. Music mode – has a higher focus on sound quality

## Cautions

1. Do not put the product in a damp, dusty, smoke or steam environment, or expose to sunlight for extended periods, do not leave in a vehicle for extended time either as it may cause malfunction.
2. Use a soft dry cloth to clean the product, do not rub harshly or may scratch the paint
3. Do not put the headphones in water, they are not waterproof.
4. Continuous use at full output may damage hearing.
5. Please charge headphone with supplied adaptive USB cable, charging with a fast charge cable may cause damage to the battery.

## Liquid Ears™

PO Box 5658 Brendale QLD Australia 4500  
Customer Support 1800 812 261

[www.liquidears.com](http://www.liquidears.com)

DESIGNED IN AUSTRALIA

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by The Crest Company is under licence. Other trademarks and trade names are those of their respective owners.

Continuous use at full output may damage hearing.  
Liquid Ears is a registered trademark.

