


T-6955VAC 5" DA SANDER T-6956VAC 6" DA SANDER BOTH WITH VACUUM



OILING INSTRUCTIONS:
OIL AFTER EACH USE WITH
A FEW DROPS OF AIRTOOL
OIL THROUGH THE AIR INLET.
RUN FOR 1 SECOND TO
COAT ALL INTERNAL PARTS.



USE 90 PSI MAXIMUM

REF #	PART #	DESCRIPTION	QTY	REF #	PART #	DESCRIPTION	QTY
1	695501	HOUSING	1	23	695523	CYLINDER	1
2	695502	HOUSING GRIP	1	24	695524	FRONT END PLATE	1
3	695503	LEVER	1	25	695525	BEARING	1
4	695504	SPRING PIN	1	26	695526	O-RING	1
5	695505	VALVE STEM	1	27	695527	LOCK RING	1
6	695506	O-RING	1	28	695528	WOODRUFF KEY	1
7	695507	EXHAUST ADAPTER	1	29	695529	COUNTERBALANCE - 3/16"	1
8	695508	MUFFLER ELEMENT	1		695629	COUNTERBALANCE - 3/16"	1
9	695509	VALVE SEAT	1	30	695530	BEARING	2
10	695510	VALVE TIP	1	31	695531	WASHER	1
11	695511	SPRING	1	32	695532	SPINDLE	1
12	695512	AIR INLET	1	34	695534	WRENCH	1
13	695513	O-RING	2	35	T-6416VV	PAD 6"	1
14	695514	REGULATOR	1		T-6415VV	PAD 5" (NOT SHOWN)	1
15	695515	SNAP RING	1				
16	695516	RETAINING RING	1	36	695536V	FITTING	1
17	695517	BEARING	1	37	695537V	SCREW	2
18	695518	REAR END PLATE	1	38	695538V	ADAPTER	1
19	695519	ROTOR	1	39	695539V	EJECTOR	1
20	695520	SPRING PIN	1	40	695540V	GUARD SHROUD	1
21	695521	O-RING	1				
22	695522	ROTOR BLADE (SET OF 5)	1				

505 N. Railroad Ave. 33435
P.O. Box 1117 33425
Boynton Beach, FL

SEE MORE OF OUR CATALOG AT
www.taylorpneumatic.com

Ph. (561)732-1111
Fax. (561)731-4412
Toll Free (800) 805-8665