


# T-7712 Decal / Paint / Rust Removal Tool



**OILING INSTRUCTIONS: OIL AFTER EACH USE WITH A FEW DROPS OF AIRTOOL OIL THROUGH THE AIR INLET. RUN FOR 1 SECOND TO COAT ALL INTERNAL PARTS**

## USE 90 PSI MAXIMUM

Ref #	Part #	Description	Qty.	Ref #	Part #	Description	Qty.
1	771201	Air Inlet	1	30	771230	Pin	2
2	771202	Muffler	1	31	771231	Planet Cage	1
3	771203	Housing	1	32	771232	Washer	1
4	771204	Pin	1	33	771233	Bearing	1
5	771205	Throttle Lever	1	34	771234	Clamp Nut	1
6	771206	O-Ring	2	35	771235	Bearing	1
7	771207	Valve Bushing	1	36	771236	Bearing	1
8	771208	O-Ring	2	37	771237	Pinion Gear	1
9	771209	Valve Stem	1	38	771238	Angle Housing	1
10	771210	Valve Spring	1	39	771239	Grease Fitting	1
11	771211	Air Regulator	1	40	771240	Bearing	1
12	771212	O-Ring	1	41	771241	Spindle	1
13	771213	O-Ring	1	42	771242	Gear	1
14	771214	Throttle Valve Plug	1	43	771243	Set Screw	1
15	771215	Bearing	1	44	771244	Bearing	1
16	771216	End Plate	1	45	771245	Bearing Cap	1
17	771217	Cylinder	1	46	771246	Wave Washer	1
18	771218	Pin	1	47	771247	Retaining Ring	1
19	771219	Pin	1	48	771248	Adapter	1
20	771220	Rotor Blades (set of 4)	1 set	49	T-771249	Eraser Pad	1
21	771221	Rotor	1	50	771250	Wrench 14mm	1
22	771222	Pin	1	51	771251	Front Cover	1
23	771223	Front End Plate	1	52	771252	Hex Nut	1
24	771224	Bearing	1	53	771253	Back Cover	1
25	771225	Washer	1	54	771254L	Long Screw	2
26	771226	Internal Gear	1	54	771254S	Short Screw	4
27	771227	Bearing	1	55	771255	Handle	1
28	771228	Planet Gear	2	56	771256	Adapter	1
29	771229	Bushing	2	57	T-771257	Stripper Wheel	1

505 N. Railroad Ave. 33435  
P.O. Box 1117 33425  
Boynton Beach, Florida

FOR WARRANTY INFORMATION &  
WARRANTY REGISTRATION VISIT  
[www.taylorpneumatic.com](http://www.taylorpneumatic.com)

Ph. (561) 732-1111  
Fax (561) 731-4412  
Toll Free 800-805-8665