
T-7724 3/8" Impact Wrench



OILING INSTRUCTIONS: OIL
AFTER EACH USE WITH A
FEW DROPS OF AIR TOOL
OIL THROUGH THE AIR
INLET. RUN FOR ONE
SECOND TO COAT ALL
INTERNAL PARTS



USE 90 PSI MAXIMU	VI
-------------------	----

OOE OF INAXIIION									
Ref #	Part #	Description	Qty.	Ref #	Part #	Description	Qty.		
1	772401	Rubber Nose Guard	1	27	772427	Bearing	1		
2	772402	Oil Seal	1	28	772428	Gasket	1		
3	772403	Oiler Screw	1	29	772429	Housing Band	1		
4	772404	Motor Housing	1	30	772430	Housing Cap	1		
5	772405	Reverse Valve Pin	1	32	772432	Cap Screw & Washers	4		
6	772406	Spring	1	33	772433	Screw	2		
7	772407	Set Screw	1	34	772434	Exhaust Cover	1		
8	772408	Housing Bushing	1	35	772435	Throttle Lever	1		
10	772410	Retaining Ring	1	36	772436	Pin	1		
11	772411	"O" Ring	1	37	772437	Push Pin	1		
12	772412	Anvil	1	38	772438	"O" Ring	1		
13	772413	Reverse Valve	1	39	772439	Gasket	1		
14	772414	Hammer Cage Pin	1	40	772440	Pin	1		
15	772415	Hammer Cage	1	41	772441	Valve Block	1		
16	772416	Cam	1	41A	772441A	Complete Valve Block	1		
17	772417	Hammer Dog	1	42	772442	"O" Ring	1		
18	772418	Bearing	1	43	772443	Regulator Valve	1		
19	772419	Oil Seal	1	45	772445	Cap Screw	2		
20	772420	"O" Ring	1	46	772446	"O" Ring	1		
21	772421	Front End Plate	1	47	772447	Throttle Valve	1		
22	772422	Motor Pin	1	49	772449	Spring	1		
23	772423	Rotor Blades (set of 6)	1 set	50	772450	Hose Adapter	1		
24	772424	Rotor	1	53	772453	"O" Ring	1		
25	772425	Cylinder	1			o rung			
26	772426	Rear End Plate	1						
ı I			1 1		1		1		

505 N. Railroad Ave. 33435 P.O. Box 1117 33425 Boynton Beach, Florida FOR WARRANTY INFORMATION & WARRANTY REGISTRATION VISIT **www.taylorpneumatic.com**

1122 TPTC /all rights reserved /COPYRIGHT 2022 / final

Ph. (561) 732-1111 Fax (561) 731-4412 Toll Free 800-805-8665

General Instructions Impact Wrenches

PLEASE READ AND FOLLOW ALL WARNINGS

An impact wrench is an amazing time saving machine. If its strengths and weaknesses are taken into consideration it can be used for years of trouble free service. Always use 90 PSI Maximum AT THE TOOL. Using higher air pressures can prematurely wear parts and strain parts not designed for the higher pressure. In most instances, within the first five seconds of use, an impact wrench develops its maximum torque. If a fastener is still not moving try penetrating oil or a larger impact wrench. Always use impact sockets. Always oil your airtools before storing. Put a few spoonfuls of airtool oil in the air inlet and run the tool for a second or two to coat internal parts.

OILING INSTRUCTIONS.

OIL AFTER EACH USE WITH 1/2 TABLESPOON OF AIRTOOL OIL THROUGH THE AIR INLET. RUN FOR ONE SECOND TO COAT ALL INTERNAL PARTS.1/4" TO 1/2" IMPACTS USAULY USE 30 WT. NON DETERGENT OIL IN THE HAMMER CASE. WRENCHES 3/4" TO 1-1/2" USUALLY USE GREASE IN THE HAMMER CASE.

IMPACT WRENCHES - GENERAL INSTRUCTIONS

- 1. ALWAYS DISCONNECT THE TOOL FROM AIR SOURCE WHEN CHANGING ACCESSORIES OR SERVICING THE TOOL.
- 2. CHECK ALL FASTENERS DAILY. BOLTS MUST BE KEPT TIGHT TO MAINTAIN SAFETY AND TOP TOOL OPERATING VPERFOR-MANCE.
- 3. STAY IN CONTROL OF THE IMPACT WRENCH
- 4. ALWAY USE IMPACT SOCKETS STANDARD SOCKETS MAY BE BRITTLE AND BREAK CAUSING DAMAGE TO THE OPERATOR OR THE TOOL.
- 5. VIBRATION MAY BE HARMFUL TO YOUR ARMS AND HANDS. WEAR PROTECTION.
- 6. INSPECT THE TOOL AND AIR SUPPLY AND AIR HOSE ON A REGULAR BASIS.
- 7. DO NOT MAKE CONTACT WITH ELECTRICAL LINES.
- 8. LEAVE TRIGGER OFF BEFORE CONNECTING THE TOOL TO THE AIR SUPPLY. AVOID ACCIDENTAL STARTS.
- 9. WEAR THE PROPER CLOTHING. DO NOT WEAR JEWELRY, LOOSE CLOTHING, OR LONG HAIR AS IT CAN GET CAUGHT IN ROTATING PARTS. KEEP GLOVES AWAY FROM ROTATING PARTS.
- 10. DO NOT WORK IN HAZARDOUS ATMOSPHERES WHERE SPARKS COULD IGNITE OR DETONATE FUMES.
- 11. WATCH WHAT YOU ARE DOING. USE COMMON SENSE WHEN OPERATING PNEUMATIC TOOLS. DO NOT USE PNEUMATIC TOOLS WHEN TIRED OR UNDER THE INFLUENCE OF MEDICATION, ALCOHOL OR DRUGS. SERIOUS PERSONAL INJURY MAY RESULT FROM A MOMENTS INATTENTION.
- 12. USE 90 PSI AT THE TOOL. USE 3/8", 1/2" or 3/4" HOSE OR LARGER WITH FITTINGS 9/32 MINIMUM I.D. AS SPECIFIED
- 13. DO NOT WORK IN HAZARDOUS ATMOSPHERES WHERE SPARKS COULD IGNITE OR DETONATE FUMES.
- 14. WATCH WHAT YOU ARE DOING. USE COMMON SENSE WHEN OPERATING PNEUMATIC TOOLS. DO NOT USE PNEUMATIC TOOLS WHEN TIRED OR UNDER THE INFLUENCE OF MEDICATION, ALCOHOL OR DRUGS. SERIOUS PERSONAL INJURY MAY RESULT FROM A MOMENTS INATTENTION.
- 15. USE 90 PSI AT THE TOOL. USE 3/8", 1/2" or 3/4" HOSE OR LARGER WITH FITTINGS 9/32 MINIMUM I.D. AS SPECIFIED
- 16. ONLY USE CLEAN DRY COMPRESSED AIR. NEVER USE OXYGEN, CARBON DIOXIDE, COMBUSTIBLE GASES OR ANY OTHER BOTTLED GAS TO POWER THIS TOOL.
- 17. STORE TOOLS IN A CLEAN DRY ENVIRONMENT.
- 18. DO NOT USE DAMAGED TOOLS MARK, AND RETURN DAMAGED TOOLS FOR SERVICE.
- 19. NEVER FORCE THE TOOL. LET THE TOOL DO THE WORK.
- 20. STOP USE IMMEDIATELY IF TOOL IS MAKING AN UNUSUAL NOISE OR VIBRATION. HAVE TOOL CHECKED BY PROFESSIONAL TECHNICIAN.
- 21. KEEP CHILDREN, PETS AND BYSTANDERS AWAY WHILE OPERATING A PNEUMATIC TOOL. DISTRACTIONS CAN CAUSE YOU TO LOSE CONTROL.
- 22. THESE WARNINGS AND INSTRUCTIONS CAN NOT COVER ALL POSSIBLE CONDITIONS OR SITUATIONS. THE OPERATOR MUST UNDERSTAND THAT COMMON SENSE AND CAUTIONS ARE FACTORS WHICH CAN NOT BE BUILT INTO THE PRODUCT BUT MUST BE SUPPLIED BY THE OPERATOR.

ADDITIONAL INFORMATION IS AVAILABLE FROM: AMERICAN NATIONAL STANDARDS INSTITUTE 11 WEST 42ND ST. NEW YORK, NY 10036

REQUEST A COPY OF ANSI B186.1 SAFETY CODE FOR PORTABLE AIR TOOLS.

LIMITED LIFETIME WARRANTY

Most products of Taylor Pneumatic are warranted to be free from defects in material and workmanship for the life of the tool. This warranty applies to the original purchaser only. This warranty does not cover tools that have been abused, misused, modified, not properly lubricated or to normal wear and tear. Taylor Pneumatic will at its option repair or replace the defective product free of charge except for shipping. Taylor Pneumatics sole liability and your exclusive remedy under this warranty is limited to the repair or replacement of the defective product. There are no other warranties expressed or implied and Taylor Pneumatic shall not be liable for incidental, consequential, or special damages, expenses or costs except as described above. WARRANTY VOID IF TOOL IS DISASSEMBLED. Return tools to Taylor Pneumatic. Be sure to include your name, address, proof of purchase and description of the suspected defect.

This warranty applies to the basic tool. It does not apply to wear and tear on accessories or consumables such as drill chucks, backing pads for sanders, punch and dies for nibblers, spray qun cups or accessories from a kit.