


# T-7789R

**1/4" ANGLE GEARLESS  
DIE GRINDER (25,000 RPM)**



**OILING INSTRUCTIONS:  
OIL AFTER EACH USE  
WITH A FEW DROPS OF  
AIRTOOL OIL THROUGH  
THE AIR INLET. RUN FOR  
1 SECOND TO COAT ALL  
INTERNAL PARTS.**



**USE 90 PSI MAXIMUM**

REF #	PART #	DESCRIPTION	QTY
1	7789R01	THROTTLE LEVER	1
2	7789R02	SPRING PIN	1
3	7789R03	HOUSING	1
4	7789R04	VALVE BUSHING	1
5	7789R05	O-RING	1
6	7789R06	VALVE STEM	1
7	7789R07	O-RING	1
8	7789R08	VALVE SPRING	1
9	7789R09	AIR CONTROLLER	1
10	7789R10	O-RING	1
11	7789R11	O-RING	1
12	7789R12	VALVE SCREW	1
13	7789R13	BEARING	1
14	7789R14	END PLATE	1
15	7789R15	PIN	2
16	7789R16	CYLINDER	1
17	7789R17	ROTOR	1
18	7789R18	BLADE (4)	1set
19	7789R19	COLLAR	1
20	7789R20	STEEL PLATE	1
21	7789R21	FRONT PLATE	1
22	7789R22	BEARING	1

REF #	PART #	DESCRIPTION	QTY
23	7789R23	SPINDLE	1
24	7789R24	LOCK RING	1
25	T-7504	COLLET 1/4"	1
25A	T-7508	COLLET 1/8" (OPTIONAL)	
26	7789R26	COLLET NUT	1
27	7789R27	EXHAUST SLEEVE	1
28	7789R28	O-RING	1
29	7789R29	AIR INLET	1
30	7789R30	WRENCH (11MM)	1
31	7789R31	WRENCH (17MM)	1

505 N. Railroad Ave. 33435  
P.O. Box 1117 33425  
Boynton Beach, FL

SEE MORE OF OUR CATALOG AT  
**[www.taylorpneumatic.com](http://www.taylorpneumatic.com)**

JUNE 2020 / ALL RIGHTS RESERVED / COPYRIGHT 2020

Ph. (561) 732-1111  
Fax. (561) 731-4412  
Toll Free (800) 805-8665