


# T-7838 H/D SEALANT CUTTER



**OILING INSTRUCTIONS:  
OIL AFTER EACH USE  
WITH A FEW DROPS OF  
AIRTOOL OIL THROUGH  
THE AIR INLET. RUN FOR  
1 SECOND TO COAT ALL  
INTERNAL PARTS.**



**USE 90 PSI MAXIMUM**

REF #	PART #	DESCRIPTION	QTY	REF #	PART #	DESCRIPTION	QTY
1	783801	MOTOR HOUSING	1	24	783824	CLAMP NUT	1
2	783802	PIN	8	25	783825	BEARING	2
3	783803	AIR INLET		26	783826	HOUSING	1
4	783804	THROTTLE LEVER COMPLETE	1	27	783827	O-RING	1
5	783805	VALVE STEM	1	28	783828	KNOB	1
6	783806	BUSHING	1	29	783829	SPINDLE	1
7	783807	O-RING	1	30	783830	WASHER	1
8	783808	SPRING	1	31	783831	SCREW	1
9	783809	O-RING	1	32	783832	WASHER	3
10	783810	THROTTLE VALVE	1	33	783833	OSCILLATOR	1
11	783811	O-RING	1	34	783834	CLAMP	1
12	783812	SPACER	1	35	783835	GREASE FITTING	1
13	783813	BEARING	1	36	783836	SCREW	4
14	783814	REAR END PLATE	1	37	783837	CRANK SHAFT	1
15	783815	ROTOR	1	38	783838	BEARING	2
16	783816	ROTOR BLADES (4 PER SET)	1set	39	783839	SEAL	1
17	783817	PIN	3	43	783843	WASHER	4
18	783818	CYLINDER	1	44	783844	PACKING	1
19	783819	FRONT END PLATE	1	47	T-783851	2-1/2" OFFSET BLADE	1
20	783820	BEARING	1	48	783848	HEX. KEY WRENCH	1
21	783821	AIR REGULATOR	1	50	783850A	EXHAUST HOSE ASSEMBLY	1
22	783822	SPACER	2	51	783851	GASKET	1

505 N. Railroad Ave. 33435  
P.O. Box 1117 33425  
Boynton Beach, FL

SEE MORE OF OUR CATALOG AT  
[www.taylorpneumatic.com](http://www.taylorpneumatic.com)

Ph. (561) 732-1111  
Fax. (561) 731-4412  
Toll Free (800) 805-8665