


T-8801REX Extended 4" Reversible Angle Cutoff Tool



OILING INSTRUCTIONS:
OIL AFTER EACH USE
WITH A FEW DROPS
OF AIRTOOL OIL
THROUGH THE AIR
INLET. RUN FOR ONE
SECOND TO COAT
ALL INTERNAL PARTS



USE 90 PSI MAXIMUM

Ref #	Part #	Description	Qty.	Ref #	Part #	Description	Qty.
1	8801REX01	FWD/REV Knob	1	39A	8801REX39A	Angle Housing	1
2	8801REX02	O-Ring	1	40	8801REX40	Cap	1
3	8801REX03	O-Ring	1	41	8801REX41	Bearing	1
4	8801REX04	Valve Stem	1	42	8801REX42	Snap Ring	1
5	8801REX05	O-Ring	1	43A	8801REX43A	Arbor Gear	1
6	8801REX06	Regulator	1	44	8801REX44	Bearing	1
7	8801REX07	Air Inlet	1	45	8801REX45	Nut	5
8	8801REX08	Muffler	1	46	8801REX46	Screw	1
10	8801REX10	Cover	1	47	8801REX47	Clamp	1
11	8801REX11	Pin	1	48A	8801REX48A	Ring	1
12	8801REX12	Lever	1	49	8801REX49	Screw	4
13	8801REX13	Spring	1	50	8801REX50	Guard	1
14	8801REX14	Valve	1	51	8801REX51	Screw	4
15	8801REX15	Valve Seat	1	52A	8801REX52A	Washer	1
16	8801REX16	Pin	1	54A	8801REX54A	Washer	1
17	8801REX17	Housing	1	55	8801REX55	Nut	1
18	8801REX18	Bearing	1	56A	8801REX56A	Screw	1
19	8801REX19	Gasket	1	58	8801REX58	Allen Wrench (4mm)	1
20	8801REX20	Rear End Plate	1	59A	8801REX59A	Spanner Wrench	1
22	8801REX22	Rotor Blade (4 per set)	1set	60	8801REX60	O-Ring	1
23	8801REX23	Rotor	1	61	8801REX61	Grease Fitting	1
24	8801REX24	Cylinder	1	62	8801REX62	Spring	1
25	8801REX25	Spacer	1	63	8801REX63	Pin	1
26	8801REX26	Pin	2	64	8801REX64	Nut	1
27	8801REX27	Front End Plate	1	70	8801REX70	Muffler	1
28	8801REX28	Bearing	1	71	8801REX71	Washer	1
29	8801REX29	Nut	1	72	8801REX72	O-Ring	1
30	8801REX30	Coupling	1	73	8801REX73	O-Ring	1
31	8801REX31	Bearing	1	77	8801REX77	Screw	1
32	8801REX32	Nut	1	78	8801REX78	Snap Ring	1
33	8801REX33	Clamp Nut	1	79	8801REX79	FWD/REV Valve	1
34A	8801REX34A	Extension Tube	1	80	8801REX80	Snap Ring	1
35	8801REX35	Drive Shaft	1	81	8801REX81	Spindle	1
36	8801REX36	Bearing	2	82	8801REX82	Key	1
37	8801REX37	Gear	1	83	8801REX83	Washer	1
38	8801REX38	Screw	1	9801341	4"Cutoff Wheel (not shown)	1	
				8801REX85	Side Handle (optional)	1	

505 N. Railroad Ave. (33435)
P.O. Box 1117 (33425)
Boynton Beach, Florida

FOR WARRANTY INFORMATION &
WARRANTY REGISTRATION VISIT
www.taylorpneumatic.com

Ph. (561) 732-1111
Fax (561) 731-4412
Toll Free 800-805-8665