PARTS

Neckpiece x1	Neckpiece Gasket x1	Base x1	Downstem Gasket x 1	Downstem x1	Glass Bowl x1
	\bigcirc			2-1 Places	

ASSEMBLY

- 1. Unpack all parts. Ensure the Downstem Gasket is oriented correctly in the Base. An upside down gasket can cause a gap that leaks air.
- 2. Unwrap and assemble the Downstem. Insert the Downstem into the Base, pushing it in until flush with the Downstem Gasket so there are no gaps. Important: If the Downstem touches the inside of the Base, remove one piece to avoid damage to the ceramic interior.



















CLEANING



WARNING: NEVER USE CLAY-BASED CLEANERS, CHEMICAL CLEANERS, OR ROCK SALT FOR CLEANING! THESE COULD DAMAGE THE CERAMIC INTERIOR AND CAUSE CORROSION.

- 1. Remove the Glass Bowl, disassemble the Downstem, and soak both parts in 70% isopropyl alcohol.
- 2. Separate the Neckpiece from the Base and thoroughly rinse both with room temperature water to remove any loose material.
- 3. Pour a generous amount of 70% isopropyl alcohol into the Base. Cap both holes and shake the Base vigorously to remove any stubborn resin. Pour out any additional loose material from Base.
- 4. Using an alcohol wipe or paper towel soaked in 70% isopropyl alcohol, wipe out the top of the Base and the inside of the neckpiece. Also wipe clean Downstem Gasket and Neckpiece Gasket.
- 5. Rinse the Base, Neckpiece, Glass Bowl and Downstem thoroughly with room temperature water until clean. Let all parts dry and make sure alcohol is evaporated before using again.