

lever-arm POWER ARC CORKSCREW

care and use instructions

Opening the bottle

Expose the cork by cutting away the foil wrap with the integral foil cutter. To do this, place the corkscrew over the top of the bottle with the lever arm raised, grip around the top of the bottle and twist it around several times, so that the blades cut the entire circumference of the foil. Remove the corkscrew and lift the top of the foil to expose the cork. Pull the lever arm up so that the worm screw is up inside the mechanism. Fit the Power Arc securely over the top of the bottle neck and squeeze the silver handle to hold in place. Push the lever arm down to spiral the screw into the cork. Still squeezing the silver handle, slowly lift the lever arm back to its vertical position to lift out the cork. To release the cork, lift the Power Arc away from the opened bottle then flip the lever down and up.

Exchanging the worm spiral

If the coating of the worm spiral is worn by frequent use it can be exchanged by the replacement spiral. Pull the lever to the top. Turn the round top cap anti-clockwise to remove it. Hold the worm screw near the top and gently rotate it anti-clockwise whilst pushing upwards. You should be able to hold the top of it to pull the worm screw free. Insert the new worm screw, making sure that the end is guided through the hole in the mechanism. Gently twisting the worm screw clockwise will ensure that the worm screw slots into the correct position. Replace the round top cap. Ensure that the top cap is screwed on firmly before use.



BAR CRAFT®

is a registered trade mark owned by

Kitchen Craft, Thomas Plant (Birmingham) Ltd

Plumbob House, Valepits Road, Garretts Green, Birmingham, B33 0TD.

established 1850. www.kitchencraft.co.uk