
CTQLIGHTING

PENDULUM FLOOR

Installation Guide



Please handle with care and wear gloves at all times during assembly and installation to avoid damaging components.

+44 (0) 20 7686 8700 ctolighting.co.uk sales@ctolighting.co.uk




TECHNICAL

Bulb Holder integrated LED - dimmable **Wattage** 8w - 2700k **Weight** 14kg (30.9lbs)

PARTS & COMPONENTS

A.1 x Pendulum floor base - With in-line dimming switch B.1 x Glass shade C.1 x Glass mount ring D. Diffuser



СТО


I

BEFORE INSTALLATION

- Check that you have all components before starting assembly. - Assembly must be carried out by a qualified electrician. **1** Remove the floor base (A) from the packaging and stand on a firm surface.




2. Place the glass shade (B) onto the body and screw on the glass mount ring (C)



3. Screw the diffuser (D) into the centre of the body.

The diffuser (D) should be screwed tight to the glass shade (B) so it is held tight and unable to move.



MAINTENANCE

Cleaning

Dust using a dry lint-free cloth weekly or as required

Repairs Contact CTO Lighting Warranty Please visit www.ctolighting.co.uk/ pages/f-a-q for CTO warranty policy Certification

ctolighting.co.uk