

H380701B DANI PENDANT

IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT

BEFORE DISCARDING THE CARTON DOUBLE CHECK THE

AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE

PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN

MOUNTED TO THE STRUCTURE OF THE BUILDING.

THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY

ORIGINAL FIXTURE WAS ATTACHED.

FOUND.

ASSEMBLY AND MOUNTING INSTRUCTIONS

GENERAL

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL **CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED**
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOUILD BE COMPLETED BY A LICENSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COULD **RESULT IN SERIOUS INJURY OR DEATH**
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

INSTALLATION

INSTALLATION			
STEP 1.	Feed the cord through the screw collar, canopy, nipple, and mounting plate until you desired hanging height is met.	STEP 6.	the wire nut with electrical tape. Repeat the previous step with the hot (black wires). Make
STEP 2.	Tie an overhand knot to secure wire in place above the nipple, and trim off excess wire to min 6" beyond the knot.		sure there are no exposed wires or strands that could cause a dangerous short circuit.
	Strip each wire end 5/8"		FAILURE TO CONNECT THE APPROPRIATE WIRES
STEP 3.	Attach the mounting plate to the outlet box using the mounting screws.		CORRECTLY COULD RESULT IN SEROIUS INJURY OR DEATH!
STEP 4.	Fasten bare ground wire to ground wire from the wall outlet	STEP 7.	Carefully place wires into Outlet Box.
	box (usually green or copper color) or connect ground wire to green screw on the mounting plate.	STEP 8.	Place the canopy with the fixture over the outlet box and fasten it by the screw collar.
STEP 5.	Connect the neutral (white) fixture wire coming from the fixture base to neutral (usually white) outlet wire. Fasten	STEP 9.	Install the lamp. The fixture is rated for 8W-LED G lamp. DO NOT EXCEED RECOMMENDED WATTAGE!
	both wires together with a plastic wire nut and tightly wrap	STEP 10.	Restore power to the circuit at breaker or fuse box.

DIMMING

The fixture can be controlled by a wall dimming device. Only use triac/electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be

provided by your local electrical distributor, home center, or hardware store.


CLEANING

Please clean with a soft, dry cloth ONLY! Do not use cleaning products.



H380701B DANI PENDANT

ASSEMBLYANDMOUNTINGDIAGRAM



WIRE NUT/TAPINGDIAGRAM

