

# Installation Instructions

Orb Chandelier 103307

**A391**

Page 1 of 1

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.**

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## To Install the Canopy (Figure 1)

### Component Parts


A	Ground Screw	F	Loop Collar
B	Crossbar	G	Canopy Loop
C	Lock Nut	H	Fixture Loop
D	Nipple	I	Chain
E	Canopy	J	Socket (6)

### Caution: Be sure power is off at the main breaker box prior to installation

1. Carefully unpack the fixture from the carton.
2. Using two machine screws (not provided), fasten the crossbar (B) to the electric box.

**Note:** A new electric box comes with screws. When replacing a fixture, retain the existing screws for use with the new fixture.

3. Thread lock nut (C), crossbar (B) and canopy loop (G) onto threaded nipple (D), leaving parts loose. Adjust the length of threaded nipple (D) in crossbar (B) so that loop collar (F) will hold canopy (E) against the ceiling with no threads showing for best appearance. When the correct adjustment is established, tighten lock nut (C) against crossbar (B) to hold adjustment.
4. Remove the crossbar (B) assembly from electrical box and remove canopy loop (G) from nipple (D).
5. Attach one end of the chain (I) to the fixture loop (H). Lace the wires through every other link of the chain (I) to the end. Slip wires and chain (I) through loop collar (F), and canopy (E). Fasten the chain (I) to the canopy loop (G).
6. Slip wires through the canopy loop (G) and nipple (D). Make sure to provide enough slack in the wire to ensure weight of fixture is supported by the chain (I). Thread canopy loop (G) onto nipple (D).
7. Using two machine screws (not provided), reattach the crossbar (B) to the electric box.
8. Using suitable wire connectors (not provided) connect fixture wires to supply wires (white to ribbed side of the fixture cord, black to smooth side). Run a pigtail lead from crossbar ground screw (A) to the junction box and connect all ground wires (bare copper or green to bare copper or green).
- Caution:** Make sure wire connectors are twisted on securely, and no bare wire is exposed.
9. Raise canopy (E) to the ceiling and secure loop collar (F) to canopy loop (G).
10. Install bulbs (*not provided*) into sockets (J).
11. Restore electricity at main breaker.



(Figure 1)

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

\* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.