



SPHERA PL 37



SPHERA PL 29




# L E U C O S®


INSTALLATION INSTRUCTIONS

## SPHERA PL 29 - SPHERA PL 37 KUBE PL

KUBE PL



**A1** Enclosed



One installer



Save instructions

Revised  
3 October 2012

**WARNING:**

- DISCONNECT POWER BEFORE INSTALLATION.
- FIXTURE TO BE INSTALLED BY A CERTIFIED ELECTRICIAN.
- INSTALL IN ACCORDANCE WITH THE NATIONAL AND LOCAL ELECTRICAL CODES.
- TAKE GREAT CARE TO AVOID SCRATCHING OR CHIPPING THE GLASS WHEN CARRYING OUT THE OPERATIONS BELOW

1. Remove corer "C" from back plate "D" by the three nuts "E".
2. Place the back plate "D" onto the J-Box and then connect the fixture's electrical wires to the supply wires.
3. Replace cover "C" and secure it by the three nuts "E".
4. Place the structure "A" on cover "C" and screws it by the three screws "G" on the corresponding threaded holes "F".
5. Insert light bulb into the lampholder and make a working test.
3. Keep the leveler "B" in the "ON" position. Carefully insert the glass diffuser to the structure and slide the leveler to the "OFF" position.  
Make sure that the glass diffuser is well secured before releasing it.
4. Restore power.

**FOR U.S.A. MARKET ONLY:**

**SPERA PL29**

Max 60W 120V - Type A19  

**SPERA PL37**


Max 100W 120V - Type A19  

**KUBE PL**

Max 100W 120V - Type A19  

For additional information please contact your local dealer or **LEUCOS USA** at:  
tel. (732) 225-0010 fax (732) 225-0250

FOR USA MARKET ONLY CIRCUIT DIAGRAM:



MOUNTS TO STANDARD JUNCTION BOX

