

INSTALLATION INSTRUCTIONS FOR 9806

For Post Lamp Fixture

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .
AVERTISSEMENT ! COUPER LE COURANT AUNIVEAU DES FUSIBLES OU DU DISJONCTEUR

HANG THE FIXTURE (Fig.1)

1. Place the fixture on the top of the POST on which is to be mounted and position as desired. Using the holes located on the POST CAP mark the holes position on the POST. Remove the fixture from the POST and drill a 1/8" diameter hole at each marked position on the POST.
2. Pull the power supply wires out from the POST and the fixture lead wires out from the POST CAP. Connect the electrical wires as shown in fig.2 make sure all wire nuts are secured .You may have to wrap connections with electrical tape. Attach the POWER SUPPLY GROUND WIRE to the FIXTURE GROUND WIRE. Using a wire connector rated for the size of wires being connected.
3. Place the connected wires down inside the POST and mount the POST CAP in place. Aligning the holes in the POST CAP with the POST, secure the POST CAP to the POST using 3 x 1/2" long set screw provided.
4. Install the light bulbs in accordance with the fixture's specification: **DO NOT EXCEED THE MAXIMUM WATTAGE RATING!** (**NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE**) place the glass the into the fixture place the LAMP COVER onto the top of the lamp compartment

Your installation is now complete. Return power to the junction box and test the fixture.

