



---

## ASSEMBLY AND MOUNTING INSTRUCTIONS

---

### GENERAL

---

- **WARNING-ALWAYS UNPLUG THE LAMP TO CUT ELECTRIC POWER OFF BEFORE INSTALLING, CLEANING, OR OTHER MAINTENANCE.**
  - **FAILURE TO INSTALL FIXTURE CORRECTLY COULD RESULT IN SERIOUS INJURY OR DEATH**
  - READ ALL INSTRUCTIONS BEFORE STARTING
- INSTALLATION.
  - BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.

---

### INSTALLATION

---

- STEP 1.** Remove the table lamp and parts from the Carton.
- STEP 2.** Attach the harp onto the fixture.
- STEP 3.** Attach the shade onto the harp.
- STEP 4.** Install the Lamp. This fixture is rated for 60-watt type A lamp. **DO NOT EXCEED RECOMMENDED WATTAGE**
- STEP 5.** Plug cord into a qualified socket of properly rated voltage.
- STEP 6.** On/Off switch installed on cord.

---

### CLEANING


---

Please clean with a soft, dry cloth ONLY! Do not use cleaning products

---

### ASSEMBLYANDMOUNTINGDIAGRAM

---





**mitzi**  
HUDSON VALLEY LIGHTING

**HL458201 VICKY LAMP**

---