


Anderson Table Lamp

Assembly Instructions

Product # KST 1161; KST 1171

1. Carefully unbox and examine all the items included in the packaging of the lamp.
2. Locate the harp portion of the lamp and install it onto the saddle.
3. Remove the finial knob from the harp.
4. Place the lamp shade and diffuser onto the harp nipple and secure with the finial knob.
5. Install the LED light bulb included in the packaging into the bulb socket.
6. Remove the protective plug cover from the plug portion of the power cord.
7. Plug the power cord into a functioning electrical outlet.
8. Use the switch to turn the lamp on and off to test that it functions properly.



Never use a light bulb over 75 watts with this portable lamp.

Notice: This portable lamp must be installed in accordance with all the applicable, local installation codes by an individual familiar with its construction, operation, and associated hazards. Please inspect the product and all its contents. Do not install the product if any damage or defect is found. Retain all the packaging material until the installation is successfully completed.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

SAVE THESE INSTRUCTIONS!



Remove plastic wrapping or dust cover from lamp shade before use to avoid risk of fire.



Only use a soft, dry cloth or feather duster to clean the lamp (including shade). Do not use any harsh abrasives or chemical agents.